

2006 CAMRY SOLARA ELECTRICAL WIRING DIAGRAM

	Section Code	Page
INTRODUCTION	A	2
HOW TO USE THIS MANUAL	B	3
TROUBLESHOOTING	C	12
ABBREVIATIONS	D	17
GLOSSARY OF TERMS AND SYMBOLS	E	18
RELAY LOCATIONS	F	20
ELECTRICAL WIRING ROUTING	G	40
SYSTEM CIRCUITS	H	62
GROUND POINT	I	292
POWER SOURCE (Current Flow Chart)	J	302
CONNECTOR LIST	K	310
PART NUMBER OF CONNECTORS	L	324
OVERALL ELECTRICAL WIRING DIAGRAM .	M	328

A INTRODUCTION

This manual consists of the following 13 sections:

No.	Section	Description
A	INDEX	Index of the contents of this manual.
	INTRODUCTION	Brief explanation of each section.
B	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
C	TROUBLE-SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
H	INDEX	Index of the system circuits.
	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to use this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
I	GROUND POINT	Shows ground positions of all parts described in this manual.
J	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
K	CONNECTOR LIST	Describes the form of the connectors for the parts appeared in this book. This section is closely related to the system circuit.
L	PART NUMBER OF CONNECTORS	Indicates the part number of the connectors used in this manual.
M	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.

FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the 2006 CAMRY SOLARA.

Applicable models: MCV31 Series
ACV30 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
• 2006 CAMRY SOLARA Repair Manual	RM1177U
• 2006 TOYOTA New Car Features	NCF290U

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.

©2005 TOYOTA MOTOR CORPORATION

All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

First Printing : Feb. 24, 2005 01-050224-00

HOW TO USE THIS MANUAL B

This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)


When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Point section). See the System Outline to understand the circuit operation.

When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.

Wiring related to each system is indicated in each system circuit by arrows (from __, to __). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.

B HOW TO USE THIS MANUAL

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.



50 — [M]

[A] : System Title

[B] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B


Example: ① Indicates Relay Block No.1

[C] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

[D] : Indicates related system.

[E] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows ().

Outside numerals are pin numbers.




The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g., "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g., IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

[F] : Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.

[G] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



[H] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black W = White BR = Brown

L = Blue V = Violet SB = Sky Blue


R = Red G = Green LG = Light Green

P = Pink Y = Yellow GR = Gray

O = Orange


The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y



[I] : Indicates a wiring Splice Point

Example:




[J] : Indicates a shielded cable.




[K] : Indicates the pin number of the connector.

The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right



Numbered in order from upper right to lower left



[L] : Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g., "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

[M] : Page No.

[N] : Indicates the ignition key position(s) when the power is supplied to the fuse(s).

B HOW TO USE THIS MANUAL

[O]

System Outline

Current is applied at all times through the STOP fuse to TERMINAL 2 of the stop light SW. When the ignition SW is turned on, current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear lights warning light to TERMINAL 4 of the light failure sensor.

Stop Light Disconnection Warning

When the ignition SW is turned on and the brake pedal is pressed (Stop light SW on), if the stop light circuit is open, the current flowing from TERMINAL 7 of the light failure sensor to TERMINALS 1, 2 changes, so the light failure sensor detects the disconnection and the warning circuit of the light failure sensor is activated.

As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on. By pressing the brake pedal, the current flowing to TERMINAL 8 of the light failure sensor keeps the warning circuit on and holds the warning light on until the ignition SW is turned off.

[P]

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C7	34	L4	36	R7	37
H17	36	R6	37	S6	35

[Q]

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	18	R/B No.1 (Instrument Panel Brace LH)

[R]

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
3C	22	Instrument Panel Wire and J/B No.3 (Instrument Panel Brace LH)
IB	20	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)

[S]

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)
BV1	50	Luggage Room Wire and Floor Wire (Luggage Room Left)

[T]

: Ground Points


Code	See Page	Ground Points Location
BL	50	Under the Left Center Pillar
BO	50	Back Panel Center

[O] : Explains the system outline.

[P] : Indicates the reference page showing the position on the vehicle of the parts in the system circuit.

Example : Part "L4" (Light Failure Sensor) is on page 36 of the manual.

* The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with that letter.

Example : L 4

 Parts is 4th in order
 Light Failure Sensor

[Q] : Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.

Example : Connector "1" is described on page 18 of this manual and is installed on the left side of the instrument panel.

[R] : Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit.

Example : Connector "3C" connects the Instrument Panel Wire and J/B No.3. It is described on page 22 of this manual, and is installed on the instrument panel left side.

[S] : Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).

Example : Connector "IE1" connects the floor wire (female) and Instrument panel wire (male). It is described on page 42 of this manual, and is installed on the left side kick panel.


[T] : Indicates the reference page showing the position of the ground points on the vehicle.

Example : Ground point "BO" is described on page 50 of this manual and is installed on the back panel center.

B HOW TO USE THIS MANUAL

The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points (\triangle^{EA} , \triangle^{IB} and \triangle^{IC} shown below) can also be checked this way.

I GROUND POINT




* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.

The "Current Flow Chart" section, describes which parts each power source (fuses, fusible links, and circuit breakers) transmits current to. In the Power Source circuit diagram, the conditions when battery power is supplied to each system are explained. Since all System Circuit diagrams start from the power source, the power source system must be fully understood.

J POWER SOURCE (Current Flow Chart)


The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuses, etc.) and other parts



Engine Room R/B (See Page 20)

Fuse	System	Page
20A STOP	ABS ABS and Traction Control Cruise Control Electronically Controlled Transmission Multiplex Communication System	194 187 180 166 210
10A DOME	Cigarette Lighter Combination Meter Headlight Interior Light Key Reminder and Seat Belt Warning Light Auto Turn Off System Rearview and Daytime Running Light	214 230 112 122


Power Source




* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.

B HOW TO USE THIS MANUAL

K CONNECTOR LIST




K CONNECTOR LIST



[A] : Indicates connector to be connected to a part. (The numeral indicates the pin No.)

[B] : Junction Connector

Indicates a connector which is connected to a short terminal.



Junction connector in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.

[C] : Parts Code

The first letter of the code is taken from the first letter of part, and the numbers indicates its order in parts which start with the same letter.

[D] : Connector Color

Connectors not indicated are milky white in color.

[E] : Indicates the connector shapes which are used to join wire harnesses.

On Left : Female connector shapes

On Right : Male connector shapes

Numbers indicate pin numbers.

[F] : Indicates connector colors. (Connectors with not indicated colors are white)

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	D 4	Diode (Courtesy)	90980-11608
A 2	A/C Condenser Fan Motor	90980-11237	D 5	Diode (Interior Light)	90980-10962
A 3	A/C Condenser Fan Relay	90980-10940	D 6	Diode (Moon Roof)	90980-11608
A 4	A/C Condenser Fan Resistor	90980-10928	D 7	Door Lock Control Relay	90980-10848
A 5	A/C Magnetic Clutch	90980-11271	D 8	Door Lock Control SW LH	90980-11148
A 6	A/T Oil Temp. Sensor	90980-11413	D 9	Door Lock Control SW RH	
[A]	ABS Actual [B]	90980-1151	D10	Door Courtesy SW LH	90980-11097
A 8	ABS Actuator	90980-11009	D11	Door Courtesy SW RH	90980-11156
A 9	ABS Speed Sensor Front LH	90980-10941	D12	Door Courtesy SW Front LH	
A10	ABS Speed Sensor Front RH	90980-11002	D13	Door Courtesy SW Front RH	90980-11156
A11	Airbag Sensor Front LH	90980-11856	D14	Door Courtesy SW Rear LH	
A12	Airbag Sensor Front RH		D15	Door Courtesy SW Rear RH	
A13	Airbag Sensor Rear LH	90980-11194	D16	Door Courtesy Lock SW LH	90980-11170
		90980-11194			RH

[A] : Part Code


[B] : Part Name

[C] : Part Number

Toyota Part Number are indicated.

Not all of the above part numbers of the connector are established for the supply.

C TROUBLESHOOTING



VOLTAGE CHECK


- Establish conditions in which voltage is present at the check point.

Example:

- [A] – Ignition SW on
- [B] – Ignition SW and SW 1 on
- [C] – Ignition SW, SW 1 and Relay on (SW 2 off)


- Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal.

This check can be done with a test light instead of a voltmeter.



CONTINUITY AND RESISTANCE CHECK


- Disconnect the battery terminal or wire so there is no voltage between the check points.
- Contact the two leads of an ohmmeter to each of the check points.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- Use a volt/ohmmeter with high impedance ($10 \text{ k}\Omega/\text{V}$ minimum) for troubleshooting of the electrical circuit.



FINDING A SHORT CIRCUIT

- Remove the blown fuse and disconnect all loads of the fuse.
- Connect a test light in place of the fuse.
- Establish conditions in which the test light comes on.

Example:

- [A] – Ignition SW on
- [B] – Ignition SW and SW 1 on
- [C] – Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2)

- Disconnect and reconnect the connectors while watching the test light.
The short lies between the connector where the test light stays lit and the connector where the light goes out.
- Find the exact location of the short by lightly shaking the problem wire along the body.


CAUTION:

- Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)**
- When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).**





DISCONNECTION OF MALE AND FEMALE CONNECTORS

To pull apart the connectors, pull on the connector itself, not the wire harness.

HINT: Check to see what kind of connector you are disconnecting before pulling apart.



C TROUBLESHOOTING



HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)

1. PREPARE THE SPECIAL TOOL

HINT : To remove the terminal from the connector, please construct and use the special tool or like object shown on the left.

2. DISCONNECT CONNECTOR

3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER.

- Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.
- Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.

NOTICE:

Do not remove the terminal retainer from connector body.

[A] For Non-Waterproof Type Connector



HINT : The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.

"Case 1"

Raise the terminal retainer up to the temporary lock position.

"Case 2"

Open the secondary locking device.



[B] For Waterproof Type Connector

HINT : Terminal retainer color is different according to connector body.

Example:

Terminal Retainer : Connector Body

Black or White : Gray

Black or White : Dark Gray



Gray or White : Black

"Case 1"

Type where terminal retainer is pulled up to the temporary lock position (Pull Type).

Insert the special tool into the terminal retainer access hole (▲Mark) and pull the terminal retainer up to the temporary lock position.


HINT : The needle insertion position varies according to the connector's shape (Number of terminals etc.), so check the position before inserting it.




"Case 2"

Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.


C TROUBLESHOOTING



Push the terminal retainer down to the temporary lock position.



(c) Release the locking lug from terminal and pull the terminal out from rear.




4. INSTALL TERMINAL TO CONNECTOR

(a) Insert the terminal.

HINT:

1. Make sure the terminal is positioned correctly.
2. Insert the terminal until the locking lug locks firmly.
3. Insert the terminal with terminal retainer in the temporary lock position.



(b) Push the secondary locking device or terminal retainer in to the full lock position.

5. CONNECT CONNECTOR










ABBREVIATIONS


















The following abbreviations are used in this manual.

A/C	=	Air Conditioning
A/T	=	Automatic Transaxle
ABS	=	Anti-Lock Brake System
ACIS	=	Acoustic Control Induction System
ACM	=	Active Control Engine Mount
AICV	=	Air Intake Control Valve
BEAN	=	Body Electronics Area Network
C/P	=	Coupe Type
CAN	=	Controller Area Network
EC	=	Electrochromic
ECU	=	Electronic Control Unit
ESA	=	Electronic Spark Advance
EVAP	=	Evaporative Emission
IC	=	Integrated Circuit
INT	=	Intermittent
J/B	=	Junction Block
LCD	=	Liquid Crystal Display
LH	=	Left-Hand
M/T	=	Manual Transaxle
R/B	=	Relay Block
RH	=	Right-Hand
SFI	=	Sequential Multiport Fuel Injection
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
TRAC	=	Traction Control
TVIP	=	TOYOTA Vehicle Intrusion Protection
VSC	=	Vehicle Stability Control
VSV	=	Vacuum Switching Valve
VVT	=	Variable Valve Timing
w/	=	With
w/o	=	Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.


E GLOSSARY OF TERMS AND SYMBOLS

 <p>BATTERY Stores chemical energy and converts it into electrical energy. Provides DC current for the auto's various electrical circuits.</p>	 <p>GROUND The point at which wiring attaches to the Body, thereby providing a return path for an electrical circuit; without a ground, current cannot flow.</p>
 <p>CAPACITOR (Condenser) A small holding unit for temporary storage of electrical voltage.</p>	 <p>HEADLIGHTS Current flow causes a headlight filament to heat up and emit light. A headlight may have either a single (1) filament or a double (2) filament</p>
 <p>CIGARETTE LIGHTER An electric resistance heating element.</p>	 <p>HORN An electric device which sounds a loud audible signal.</p>
 <p>CIRCUIT BREAKER Basically a reusable fuse, a circuit breaker will heat and open if too much current flows through it. Some units automatically reset when cool, others must be manually reset.</p>	 <p>IGNITION COIL Converts low-voltage DC current into high-voltage ignition current for firing the spark plugs.</p>
 <p>DIODE A semiconductor which allows current flow in only one direction.</p>	 <p>LIGHT Current flow through a filament causes the filament to heat up and emit light.</p>
 <p>DIODE, ZENER A diode which allows current flow in one direction but blocks reverse flow only up to a specific voltage. Above that potential, it passes the excess voltage. This acts as a simple voltage regulator.</p>	 <p>PHOTODIODE The photodiode is a semiconductor which controls the current flow according to the amount of light.</p>
 <p>DISTRIBUTOR, IIA Channels high-voltage current from the ignition coil to the individual spark plugs.</p>	 <p>METER, ANALOG Current flow activates a magnetic coil which causes a needle to move, thereby providing a relative display against a background calibration.</p>
  <p>(for Medium Current Fuse)</p>  <p>(for High Current Fuse or Fusible Link)</p> <p>FUSE A thin metal strip which burns through when too much current flows through it, thereby stopping current flow and protecting a circuit from damage.</p> <p>FUSIBLE LINK A heavy-gauge wire placed in high amperage circuits which burns through on overloads, thereby protecting the circuit. The numbers indicate the crosssection surface area of the wires.</p>	 <p>METER, DIGITAL Current flow activates one or many LED's, LCD's, or fluorescent displays, which provide a relative or digital display.</p>  <p>MOTOR A power unit which converts electrical energy into mechanical energy, especially rotary motion.</p>


<p>RELAY 1. NORMALLY CLOSED  2. NORMALLY OPEN </p>	<p>SPEAKER An electromechanical device which creates sound waves from current flow.</p>
<p>RELAY, DOUBLE THROW A relay which passes current through one set of contacts or the other. </p>	<p>SWITCH, MANUAL 1. NORMALLY OPEN  2. NORMALLY CLOSED </p>
<p>RESISTOR An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value. </p>	<p>SWITCH, DOUBLE THROW A switch which continuously passes current through one set of contacts or the other. </p>
<p>RESISTOR, TAPPED A resistor which supplies two or more different non adjustable resistance values. </p>	<p>SWITCH, IGNITION A key operated switch with several positions which allows various circuits, particularly the primary ignition circuit, to become operational. </p>
<p>RESISTOR, VARIABLE or RHEOSTAT A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat. </p>	<p>SWITCH, WIPER PARK Automatically returns wipers to the stop position when the wiper switch is turned off. </p>
<p>SENSOR (Thermistor) A resistor which varies its resistance with temperature. </p>	<p>TRANSISTOR A solidstate device typically used as an electronic relay; stops or passes current depending on the voltage applied at "base". </p>
<p>SENSOR, SPEED (Reed Switch Type) Uses magnetic impulses to open and close a switch to create a signal for activation of other components. </p>	<p>WIRES (1) NOT CONNECTED  (2) SPLICED </p>
<p>SHORT PIN Used to provide an unbroken connection within a junction block. </p> <p>SOLENOID An electromagnetic coil which forms a magnetic field when current flows, to move a plunger, etc. </p>	<p>Wires are always drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not joined; crossed wires (2) with a black dot or octagonal (○) mark at the junction are spliced (joined) connections.</p>

F RELAY LOCATIONS


[Engine Compartment]




[Instrument Panel]



**[Body]
(C/P)**




(Convertible)



F RELAY LOCATIONS


[Seat]



F RELAY LOCATIONS


① : Engine Room R/B

Engine Compartment Left (See Page 20)



(②) : VSC R/B


Engine Compartment Left (See Page 20)




F RELAY LOCATIONS

 : Engine Room J/B


Engine Compartment Left (See Page 20)





F RELAY LOCATIONS


[Engine Room J/B Inner Circuit]




F RELAY LOCATIONS

○ : Driver Side J/B

Lower Finish Panel (See Page 20)







F RELAY LOCATIONS

○ : Driver Side J/B

Lower Finish Panel (See Page 20)



[Driver Side J/B Inner Circuit]




(Cont. Next Page)

F RELAY LOCATIONS


[Driver Side J/B Inner Circuit]

(Cont' d)



(Cont. Next Page)


(Cont' d)




F RELAY LOCATIONS

 : Passenger Side J/B Instrument Panel Brace RH (See Page 20)
(C/P, Convertible w/ VSC)

(from Instrument Panel Wire)




Short Terminal Grouping




 : Passenger Side J/B
(Convertible w/o VSC)

Instrument Panel Brace RH (See Page 20)

(from Instrument Panel Wire)




Short Terminal Grouping




F RELAY LOCATIONS

Junction Connector (CAN)	Instrument Panel Brace LH (See Page 20)
-----------------------------	---



[Junction Connector Inner Circuit] (CAN)


J5(A), J6(B), J7(C), J8(D), J9(E)
Junction Connector



G ELECTRICAL WIRING ROUTING

Position of Parts in Engine Compartment


[3MZ-FE]



- | | |
|---|--|
| A 1 A/C Ambient Temp. Sensor | F 1 Front Fog Light LH |
| A 2 A/C Lock Sensor | F 2 Front Fog Light RH |
| A 3 A/C Magnetic Clutch | F 3 Front Parking Light LH |
| A 4 A/T Indicator Light SW | Front Turn Signal Light LH |
| Back-Up Light SW | F 4 Front Turn Signal Light RH |
| Park/Neutral Position SW | Front Wiper Motor |
| A 5 ABS Speed Sensor Front LH | |
| A 6 ABS Speed Sensor Front RH | |
| A 7 Air Fuel Ratio Sensor (Bank 1 Sensor 1) | G 1 Generator |
| A 8 Air Fuel Ratio Sensor (Bank 2 Sensor 1) | G 2 Generator |
| A 9 Airbag Sensor Front LH | |
| A10 Airbag Sensor Front RH | |
| B 2 Brake Fluid Level Warning SW | H 1 Headlight LH (High) |
| C 2 Condenser Fan Motor | H 2 Headlight LH (Low) |
| C 3 Counter Gear Speed Sensor | H 3 Headlight RH (High) |
| C 4 Crankshaft Position Sensor | H 4 Headlight RH (Low) |
| D 1 Diode (A/C No.1) | H 5 Heated Oxygen Sensor (Bank 1 Sensor 2) |
| E 1 Electronically Controlled Transmission Solenoid | H 6 Heated Oxygen Sensor (Bank 2 Sensor 2) |
| E 2 Engine Coolant Temp. Sensor | H 7 Horn LH |
| E 3 Engine Hood Courtesy SW | H 8 Horn RH |
| | H 9 |

Position of Parts in Engine Compartment

[3MZ-FE]



| 1 Ignition Coil and Igniter No.1
 | 2 Ignition Coil and Igniter No.2
 | 3 Ignition Coil and Igniter No.3
 | 4 Ignition Coil and Igniter No.4
 | 5 Ignition Coil and Igniter No.5
 | 6 Ignition Coil and Igniter No.6
 | 7 Injector No.1
 | 8 Injector No.2
 | 9 Injector No.3
 | 10 Injector No.4
 | 11 Injector No.5
 | 12 Injector No.6

K 1 Keyless Buzzer
 K 3 Knock Sensor (Bank 1)
 K 4 Knock Sensor (Bank 2)

M 1 Mass Air Flow Meter

N 1 Noise Filter (Ignition)
 N 2 Noise Filter (Rear Window Defogger)

O 1 Oil Pressure SW

P 1 Power Steering Oil Pressure SW
 P 2 Pressure SW

R 1 Radiator Fan Motor

S 1 Skid Control ECU with Actuator
 S 2 Skid Control ECU with Actuator
 S 3 Starter
 S 4 Starter

T 1 Theft Deterrent Horn
 T 2 Throttle Control Motor
 Throttle Position Sensor
 T 3 Turbine Speed Sensor


V 2 VSV (ACIS)
 V 3 VSV (ACM)
 V 4 VSV (AICV)
 V 5 VSV (EVAP)
 V 6 VVT Sensor LH
 V 7 VVT Sensor RH
 V 9 VVT Solenoid LH
 V10 VVT Solenoid RH

W 1 Washer Level Sensor
 W 2 Washer Motor
 W 3 Water Temp. SW No.1
 W 4 Water Temp. SW No.2

G ELECTRICAL WIRING ROUTING

Position of Parts in Engine Compartment

[2AZ-FE]



- A 1 A/C Ambient Temp. Sensor
- A 2 A/C Lock Sensor
- A/C Magnetic Clutch
- A 3 A/T Indicator Light SW
- Back-Up Light SW
- Park/Neutral Position SW
- A 4 ABS Speed Sensor Front LH
- A 5 ABS Speed Sensor Front RH
- A 6 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
- A 9 Airbag Sensor Front LH
- A10 Airbag Sensor Front RH

- B 1 Back-Up Light SW
- B 2 Brake Fluid Level Warning SW

- C 1 Camshaft Position Sensor
- C 2 Condenser Fan Motor
- C 3 Counter Gear Speed Sensor
- C 4 Crankshaft Position Sensor

- D 1 Diode (A/C No.1)
- D 2 Diode (A/C No.2)

- E 1 Electronically Controlled Transmission Solenoid
- E 2 Engine Coolant Temp. Sensor
- E 3 Engine Hood Courtesy SW


- F 1 Front Fog Light LH
- F 2 Front Fog Light RH
- F 3 Front Parking Light LH
- Front Turn Signal Light LH
- F 4 Front Parking Light RH
- Front Turn Signal Light RH
- F 5 Front Wiper Motor

- G 1 Generator
- G 2 Generator

- H 1 Headlight LH (High)
- H 2 Headlight LH (Low)
- H 3 Headlight RH (High)
- H 4 Headlight RH (Low)
- H 5 Heated Oxygen Sensor (Bank 1 Sensor 2)
- H 8 Horn LH
- H 9 Horn RH

Position of Parts in Engine Compartment

[2AZ-FE]



I 1 Ignition Coil and Igniter No.1
I 2 Ignition Coil and Igniter No.2
I 3 Ignition Coil and Igniter No.3
I 4 Ignition Coil and Igniter No.4
I 7 Injector No.1
I 8 Injector No.2
I 9 Injector No.3
I 10 Injector No.4

K 1 Keyless Buzzer
K 2 Knock Sensor (Bank 1)

M 1 Mass Air Flow Meter

N 1 Noise Filter (Ignition)
N 2 Noise Filter (Rear Window Defogger)

O 1 Oil Pressure SW

P 1 Power Steering Oil Pressure SW
P 2 Pressure SW

R 1 Radiator Fan Motor

S 2 Skid Control ECU with Actuator
S 3 Starter
S 4 Starter

T 1 Theft Deterrent Horn
T 2 Throttle Control Motor
Throttle Position Sensor
T 3 Turbine Speed Sensor


V 5 VSV (EVAP)
V 8 VVT Solenoid

W 1 Washer Level Sensor
W 2 Washer Motor

G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[C/P]



A 11 A/C Control Assembly
 A 12 A/C Room Temp. Sensor
 A 13 A/C Solar Sensor
 A 14 A/C Thermistor
 A 16 A/T Shift Lever Illumination
 Transmission Control SW
 A 17 Accelerator Pedal Position Sensor
 A 18 Air Inlet Control Servo Motor
 A 19 Air Mix Control Servo Motor
 A 20 Air Vent Mode Control Servo Motor
 A 21 Airbag Sensor Assembly
 A 22 Airbag Sensor Assembly
 A 23 Airbag Sensor Assembly
 A 24 Airbag Squib (Front Passenger Airbag Assembly)
 A 25 Airbag Squib (Front Passenger Airbag Assembly)
 A 26 Airbag Squib (Steering Wheel Pad)
 A 27 Automatic Light Control Sensor
 A 31 A/C Control Assembly
 A 32 A/C Control Assembly
 A 33 A/C Amplifier

B 3 Blower Motor
 B 4 Blower Motor Controller
 B 5 Blower Resistor
 B 6 Body ECU
 B 7 Body ECU
 B 8 Body ECU
 B 9 Body ECU

C 5 Clock
 C 6 Clutch Start SW
 C 7 Combination Meter
 C 8 Combination Meter
 C 9 Combination SW
 C 10 Combination SW
 C 11 Combination SW
 C 12 Cruise Control Clutch SW

D 3 Data Link Connector 3
 D 4 Door Control Receiver


 E 4 Engine Control Module
 E 5 Engine Control Module
 E 6 Engine Control Module
 E 7 Engine Control Module
 E 8 Engine Control Module

G 3 Glove Box Light
 G 6 Gateway ECU

H10 Hazard SW
 H11 Heater Control SW
 H12 Heater Control SW

Position of Parts in Instrument Panel

[C/P]



I 14 Ignition Key Cylinder Light
Transponder Key Amplifier

I 15 Ignition SW

J 1 Junction Connector
J 2 Junction Connector
J 3 Junction Connector
J 4 Junction Connector
J 5 Junction Connector
J 6 Junction Connector
J 7 Junction Connector
J 8 Junction Connector
J 9 Junction Connector
J 10 Junction Connector
J 11 Junction Connector
J 12 Junction Connector

P 3 Parking Brake SW
P 4 Power Outlet (Front)
P 5 Power Outlet (Rear)
P 6 Pressure SW

R 2 Radio and Player
R 3 Radio and Player
R 4 Radio and Player
R 5 Radio and Player with Display
R 6 Radio and Player with Display (w/ Navigation System)
Radio and Player (w/o Navigation System)
R 7 Radio and Player with Display (w/ Navigation System)
Radio and Player (w/o Navigation System)
R 8 Remote Control Mirror SW

S 5 Seat Heater SW (Driver's Seat)
S 6 Seat Heater SW (Front Passenger's Seat)
S 7 Security Indicator
S 8 Shift Lock Control ECU
Transmission Control SW
S 9 Steering Sensor
S 10 Stereo Component Amplifier
S 11 Stereo Component Amplifier
S 12 Stop Light SW

T 4 TRAC Off SW
T 5 Transponder Key Computer
T 6 Turn Signal Flasher Relay
T 7 Tweeter LH
T 8 Tweeter RH

U 1 Unlock Warning SW
U 2 Upper Console Panel Sub-Assembly

V 11 VSC Buzzer


Y 1 Yaw Rate Sensor

Z 1 Option Connector (TVIP ECU)
Z 2 Option Connector (TVIP Glass Breakage Sensor ECU)

G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[Convertible]



A 11 A/C Control Assembly
 A 12 A/C Room Temp. Sensor
 A 13 A/C Solar Sensor
 A 14 A/C Thermistor
 A 16 A/T Shift Lever Illumination
 Transmission Control SW
 A 17 Accelerator Pedal Position Sensor
 A 18 Air Inlet Control Servo Motor
 A 19 Air Mix Control Servo Motor
 A 20 Air Vent Mode Control Servo Motor
 A 21 Airbag Sensor Assembly
 A 22 Airbag Sensor Assembly
 A 23 Airbag Sensor Assembly
 A 24 Airbag Squib (Front Passenger Airbag Assembly)
 A 25 Airbag Squib (Front Passenger Airbag Assembly)
 A 26 Airbag Squib (Steering Wheel Pad)
 A 27 Automatic Light Control Sensor

B 3 Blower Motor
 B 4 Blower Motor Controller
 B 5 Blower Resistor
 B 6 Body ECU
 B 7 Body ECU
 B 8 Body ECU
 B 9 Body ECU


C 5 Clock
 C 6 Clutch Start SW
 C 7 Combination Meter
 C 8 Combination Meter
 C 9 Combination SW
 C 10 Combination SW
 C 11 Combination SW
 C 12 Cruise Control Clutch SW

D 3 Data Link Connector 3
 D 4 Door Control Receiver
 E 4 Engine Control Module
 E 5 Engine Control Module
 E 6 Engine Control Module
 E 7 Engine Control Module
 E 8 Engine Control Module

G 3 Glove Box Light
 H10 Hazard SW
 H11 Heater Control SW
 H12 Heater Control SW

Position of Parts in Instrument Panel

[Convertible]



I 14 Ignition Key Cylinder Light
Transponder Key Amplifier
I 15 Ignition SW

J 1 Junction Connector
J 2 Junction Connector
J 3 Junction Connector
J 4 Junction Connector
J 5 Junction Connector
J 6 Junction Connector
J 7 Junction Connector
J 8 Junction Connector
J 9 Junction Connector
J 10 Junction Connector
J 11 Junction Connector
J 12 Junction Connector

P 3 Parking Brake SW
P 4 Power Outlet (Front)
P 5 Power Outlet (Rear)
P 6 Pressure SW
P 19 Power Window SW (All Window)

R 2 Radio and Player
R 3 Radio and Player
R 4 Radio and Player
R 5 Radio and Player with Display
R 6 Radio and Player with Display (w/ Navigation System)
 Radio and Player (w/o Navigation System)
R 7 Radio and Player with Display (w/ Navigation System)
 Radio and Player (w/o Navigation System)
R 8 Remote Control Mirror SW

S 5 Seat Heater SW (Driver's Seat)
S 6 Seat Heater SW (Front Passenger's Seat)
S 7 Security Indicator
S 8 Shift Lock Control ECU
 Transmission Control SW
S 9 Steering Sensor
S 10 Stereo Component Amplifier
S 11 Stereo Component Amplifier
S 12 Stop Light SW
S 17 Sliding Roof Control SW

T 4 TRAC Off SW
T 5 Transponder Key Computer
T 6 Turn Signal Flasher Relay
T 7 Tweeter LH
T 8 Tweeter RH

U 1 Unlock Warning SW
U 2 Upper Console Panel Sub-Assembly

V 11 VSC Buzzer


Y 1 Yaw Rate Sensor

Z 1 Option Connector (TVIP ECU)
Z 2 Option Connector (TVIP Glass Breakage Sensor ECU)

G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[C/P]



A28 ABS Speed Sensor Rear LH

A29 ABS Speed Sensor Rear RH

A30 Antenna Amplifier

B10 Buckle SW LH

Seat Position Sensor

B11 Buckle SW RH

C13 Curtain Shield Airbag Sensor LH

C14 Curtain Shield Airbag Sensor RH

C15 Curtain Shield Airbag Squib LH

C16 Curtain Shield Airbag Squib RH

D 5 Door Courtesy SW LH

D 6 Door Courtesy SW RH

D 7 Door Key Lock and Unlock SW LH

Door Lock Motor LH

Door Unlock Detection SW LH

D 8 Door Lock Control SW LH

Power Window Master SW

D 9 Door Lock Control SW RH

D10 Door Lock Motor RH

Door Unlock Detection SW RH

D11 Door Side Airbag Sensor LH

D12 Door Side Airbag Sensor RH

F 6 Front Door Speaker LH

F 7 Front Door Speaker RH

F 8 Fuel Pump

Fuel Sender

G 4 Garage Door Opener

Moon Roof Control SW

Personal Light

H13 High Mounted Stop Light

I 16 Inner Mirror

I 17 Interior Light

L 1 License Plate Light

L 2 Luggage Compartment Light

L 3 Luggage Compartment Door Opener Motor

Luggage Compartment Light SW

M 2 Mirror Heater LH

Remote Control Mirror LH


M 3 Mirror Heater RH

Remote Control Mirror RH

M 4 Moon Roof Control ECU and Motor

Position of Parts in Body

[C/P]



N 4 Noise Filter (Rear Window Defogger)

N 5 Noise Filter
(Stop Light and Luggage Compartment Light)

S13 Seat Heater (Front Passenger's Seat)

S14 Side Airbag Squib LH

S15 Side Airbag Squib RH

P 7 Power Window Motor Front LH

P 8 Power Window Motor Front RH

P 9 Power Window SW Front RH

P10 Pretensioner LH

P11 Pretensioner RH

V12 Vanity Light LH

V13 Vanity Light RH

V14 Vapor Pressure Sensor

V15 VSV (Canister Closed Valve)

R 9 Rear Combination Light LH

R10 Rear Combination Light RH

R11 Rear Speaker LH

R12 Rear Speaker RH


R13 Rear Window Defogger

R14 Rear Window Defogger

G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[Convertible]



A28 ABS Speed Sensor Rear LH
 A29 ABS Speed Sensor Rear RH
 A30 Antenna Amplifier

B10 Buckle SW LH
 Seat Position Sensor
 B11 Buckle SW RH

C17 Convertible Roof Control Relay
 C18 Convertible Roof Control Relay
 C19 Convertible Roof Control Relay
 C20 Convertible Roof Courtesy SW
 C21 Convertible Roof Motor LH
 C22 Convertible Roof Motor RH
 C23 Courtesy Light Rear RH

D 5 Door Courtesy SW LH
 D 6 Door Courtesy SW RH
 D 7 Door Key Lock and Unlock SW LH
 Door Lock Motor LH
 Door Unlock Detection SW LH
 D 8 Door Lock Control SW LH
 Power Window Master SW
 D 9 Door Lock Control SW RH
 D10 Door Lock Motor RH
 Door Unlock Detection SW RH
 D11 Door Side Airbag Sensor LH
 D12 Door Side Airbag Sensor RH

F 6 Front Door Speaker LH
 F 7 Front Door Speaker RH
 F 8 Fuel Pump
 Fuel Sender

G 5 Garage Door Opener
 Vanity Light LH

H13 High Mounted Stop Light

I 16 Inner Mirror


J 15 Junction Connector
 J 16 Junction Connector
 J 17 Junction Connector

L 1 License Plate Light
 L 2 Luggage Compartment Light
 L 3 Luggage Compartment Door Opener Motor
 Luggage Compartment Light SW

M 2 Mirror Heater LH
 Remote Control Mirror LH
 M 3 Mirror Heater RH
 Remote Control Mirror RH

Position of Parts in Body

[Convertible]



N 7 Noise Filter (Rear Window Defogger)

P 7 Power Window Motor Front LH

P 8 Power Window Motor Front RH

P 9 Power Window SW Front RH

P 10 Pretensioner LH

P 11 Pretensioner RH

P 20 Personal Light

Q 1 Quarter Power Window Motor LH

Q 2 Quarter Power Window Motor RH

R 9 Rear Combination Light LH

R 10 Rear Combination Light RH

R 11 Rear Speaker LH

R 12 Rear Speaker RH

R 15 Rear Window Defogger

S 13 Seat Heater (Front Passenger's Seat)

S 14 Side Airbag Squib LH

S 15 Side Airbag Squib RH

V 13 Vanity Light RH


V 14 Vapor Pressure Sensor

V 15 VSV (Canister Closed Valve)

W 5 Woofer

G ELECTRICAL WIRING ROUTING

Position of Parts in Seat



J 13 Junction Connector

J 14 Junction Connector

O 2 Occupant Classification ECU

O 3 Occupant Classification ECU

O 4 Occupant Classification Sensor Front LH

O 5 Occupant Classification Sensor Front RH

O 6 Occupant Classification Sensor Rear LH

O 7 Occupant Classification Sensor Rear RH

P 12 Power Seat Control SW

(Driver's Seat Lumbar Support Control)

P 13 Power Seat Control SW (Driver's Seat)

P 14 Power Seat Motor (Driver's Seat Front Vertical Control)

P 15 Power Seat Motor (Driver's Seat Lifter Control)

P 16 Power Seat Motor

(Driver's Seat Lumbar Support Control)

P 17 Power Seat Motor (Driver's Seat Reclining Control)

P 18 Power Seat Motor (Driver's Seat Slide Control)


S16 Seat Heater (Driver's Seat)

G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[3MZ-FE]



□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[2AZ-FE]




G ELECTRICAL WIRING ROUTING

: Location of Connector Joining Wire Harness and Wire Harness

[C/P]




: Location of Ground Points



: Location of Connector Joining Wire Harness and Wire Harness


[C/P]




G ELECTRICAL WIRING ROUTING

: Location of Connector Joining Wire Harness and Wire Harness


[Convertible]



▽ : Location of Ground Points




: Location of Connector Joining Wire Harness and Wire Harness
[Convertible]



G ELECTRICAL WIRING ROUTING


▽ : Location of Ground Points

[C/P]





▽ : Location of Ground Points

[Convertible]




Power Source





Power Source



: Parts Location

Code	See Page	Code	See Page	Code	See Page
G1	40 (3MZ-FE)	I15	45 (C/P)		
	42 (2AZ-FE)		47 (*1)		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
1D		
1E		
1F		
1G		
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2B		
2I	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG5	56 (C/P)	
	58 (*1)	
IG8	56 (C/P)	
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Starting and Ignition for 3MZ-FE





Starting and Ignition for 3MZ-FE

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	40 (3MZ-FE)	I4	41 (3MZ-FE)	J3	47 (*1)
E8	E	I5	41 (3MZ-FE)	N1	41 (3MZ-FE)
	44 (C/P)	I6	41 (3MZ-FE)	S3	A 41 (3MZ-FE)
	46 (*1)			S4	B 41 (3MZ-FE)
I1	41 (3MZ-FE)	I15	45 (C/P)		
I2	41 (3MZ-FE)		47 (*1)		
I3	41 (3MZ-FE)	J3	45 (C/P)		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
1E		
1H		
1J		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
1L		
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2I	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG8	56 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	58 (*1)	
IM2	57 (C/P)	
	59 (*1)	


: Ground Points

Code	See Page	Ground Points Location
EE	54 (3MZ-FE)	Right Side of Cylinder Head
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Starting and Ignition for 2AZ-FE





Starting and Ignition for 2AZ-FE

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	42 (2AZ-FE)	I2	43 (2AZ-FE)	N1	43 (2AZ-FE)
C6	44 (C/P)	I3	43 (2AZ-FE)	S3	A 43 (2AZ-FE)
E4	A 44 (C/P)	I4	43 (2AZ-FE)	S4	B 43 (2AZ-FE)
E8	E 44 (C/P)	I15	45 (C/P)		
I1	43 (2AZ-FE)	J3	45 (C/P)		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A		
1C		
1E	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1H		
1J		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
1L		
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2I	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)


: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG2		
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IM2	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)

: Ground Points

Code	See Page	Ground Points Location
EH	55 (2AZ-FE)	Left Side of Cylinder Head
II	56 (C/P)	Cowl Side Panel LH

Headlight





Headlight

System Outline

Daytime Running Light Operation

When the engine is started, a signal from the generator is input into TERMINAL (D) 5 of the body ECU. At this time, if the parking brake pedal is depressed (Parking brake SW ON), the body ECU is not activated, and the daytime running light system does not operate.

When the parking brake pedal or parking lever is released (Parking brake SW OFF), a signal is input into TERMINAL 19 of the body ECU. This activates the body ECU and the headlight turns on.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A27	44 (C/P)	C9	44 (C/P)	J3	45 (C/P)
	46 (*1)		46 (*1)		47 (*1)
B6	A	G2	40 (3MZ-FE)	J4	45 (C/P)
			42 (2AZ-FE)		47 (*1)
B7	B	H1	40 (3MZ-FE)	J10	45 (C/P)
			42 (2AZ-FE)		47 (*1)
B9	D	H2	40 (3MZ-FE)	J11	45 (C/P)
			42 (2AZ-FE)		47 (*1)
C7	A	H3	40 (3MZ-FE)	P3	45 (C/P)
			42 (2AZ-FE)		47 (*1)
C8	B	H4	40 (3MZ-FE)		
			42 (2AZ-FE)		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1E		
1F		
1G		
1H		
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H	31	
2M	30	
2N		Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3A	36 (*2)	
	37 (*3)	
3B	36 (*2)	
3C	37 (*3)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC




: Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	58 (*1)	Instrument Panel Brace LH
IK	56 (C/P)	
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Fog Light



 : Parts Location

Code		See Page	Code	See Page	Code	See Page
B6	A	44 (C/P)	C9	46 (*1)	J3	45 (C/P)
		46 (*1)	F1	40 (3MZ-FE)	J4	45 (C/P)
B9	D	44 (C/P)		42 (2AZ-FE)		47 (*1)
		46 (*1)	F2	40 (3MZ-FE)		
C9		44 (C/P)		42 (2AZ-FE)		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)	
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2C			
2D			
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2H	31		
2I			
2L	30		
2M			

 : Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	58 (*1)	Instrument Panel Brace LH
IK	56 (C/P)	
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Automatic Light Control



System Outline

The automatic light control system works when the light control SW is turned to AUTO. The automatic light control sensor detects the brightness around the vehicle. By this function, the system automatically turns the taillight and headlight on if the brightness is below the regular level and turns the taillight and headlight off when the surroundings become brighter than the regular level.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A27	44 (C/P)	B8	C	46 (*1)	J3 45 (C/P)
	46 (*1)	C9	44 (C/P)	46 (*1)	J4 45 (C/P) 47 (*1)
B6	A 44 (C/P)				
	46 (*1)	D5	48 (C/P)	50 (*1)	J12 A 45 (C/P) B 47 (*1)
B8	C 44 (C/P)				

□ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1H	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2D		
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H		
2M	30	

□ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	

▽ : Ground Points

Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	58 (*1)	Instrument Panel Brace LH
IK	56 (C/P)	
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Light Auto Turn Off System



System Outline

1. Normal Lighting Operation

<Turn taillight on>

With the light control SW turned to TAIL position, a signal is input into TERMINAL (A) 17 of the body ECU. Due to this signal, the current flowing to TERMINAL 7 of the ECU flows to TERMINAL (A) 17 to TERMINAL 14 of the light control SW to TERMINAL 16 to GROUND, and TAIL relay causes taillights to turn on.

<Turn headlight on>

With the light control SW turned to HEAD position, a signal is input into TERMINALS (A) 17 and (A) 23 of the body ECU. Due to this signal, the current flowing to TERMINAL 8 of the ECU flows to TERMINAL (A) 23 to TERMINAL 13 of the light control SW to TERMINAL 16 to GROUND in the headlight circuit, and causes taillight and HEAD relay to turn the lights on. The taillight circuit is same as above.

2. Light Auto Turn Off Operation

With light on and ignition SW turned off (Input signal goes to TERMINAL 15 of the ECU), when the driver's door is opened (Input signal goes to TERMINAL (C) 14 of the ECU), the body ECU operates and the current is cut off which flows from TERMINAL 7 of the ECU to TERMINAL (A) 17 In taillight circuit and from TERMINAL 8 to TERMINAL (A) 23 in headlight circuit.

As a result, all lights are turned off automatically.

: Parts Location

Code		See Page	Code	See Page	Code		See Page
B6	A	44 (C/P)	C9	46 (*1)	J4		47 (*1)
		46 (*1)	D5	48 (C/P)	J12	A	45 (C/P)
B8	C	44 (C/P)		50 (*1)		B	47 (*1)
		46 (*1)	J3	45 (C/P)			
C9		44 (C/P)	J4	45 (C/P)			

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1H	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2D		
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H		
2M	30	

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	

: Ground Points


Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	58 (*1)	Instrument Panel Brace LH
	56 (C/P)	
IK	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Interior Light



B 7(B), B 8(C)
Body ECU



Interior Light



 : Parts Location

Code		See Page	Code		See Page	Code		See Page
B7	B	44 (C/P)	D6		50 (*1)	J17	B	50 (*1)
		46 (*1)	G4		48 (C/P)		A	48 (C/P)
B8	C	44 (C/P)	G5		50 (*1)	L2	B	50 (*1)
		46 (*1)	I14		45 (C/P)		L3	
C7	A	44 (C/P)			47 (*1)		N5	
		46 (*1)	I17		48 (C/P)		P20	
C23		50 (*1)	J3		45 (C/P)	V12		51 (*1)
D5	48 (C/P)		J12	A	45 (C/P)	V13	A	49 (C/P)
	50 (*1)			B	47 (*1)		B	51 (*1)
D6	48 (C/P)		J16	A	50 (*1)			

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G		
2H	31	
2I		
2L	30	
2M		
2P	30	Floor Wire and Driver Side J/B (Lower Finish Panel)
2R	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IE1	56 (C/P)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
	58 (*1)	
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
	58 (*1)	
IO2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR1	59 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	58 (*1)	Instrument Panel Brace LH


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Illumination





Illumination





Illumination

: Parts Location

Code		See Page		Code		See Page		Code		See Page			
A11	A	44 (C/P)		G3		44 (C/P)		R2	A	47 (*1)			
		46 (*1)				46 (*1)				45 (C/P)			
A16		44 (C/P)		H10	A	44 (C/P)		R3	B	47 (*1)			
		46 (*1)				46 (*1)				45 (C/P)			
A32	C	44 (C/P)		H11	A	44 (C/P)		R4	C	47 (*1)			
B6	A	44 (C/P)				46 (*1)				45 (C/P)			
		46 (*1)		J3		45 (C/P)		R6	B	47 (*1)			
C5		44 (C/P)				47 (*1)				45 (C/P)			
		46 (*1)		J4		45 (C/P)		R7	C	47 (*1)			
C7	A	44 (C/P)		J10	A	47 (*1)		S5	45 (C/P)		47 (*1)		
		46 (*1)				45 (C/P)				47 (*1)			
C8	B	44 (C/P)		J11	B	47 (*1)		S6	45 (C/P)		47 (*1)		
		46 (*1)				45 (C/P)				45 (C/P)			
C9		44 (C/P)		J12	A	47 (*1)		U2	47 (*1)		45 (C/P)		
		46 (*1)				45 (C/P)				47 (*1)			
C10		44 (C/P)		R2	A	47 (*1)							
		46 (*1)				45 (C/P)							

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G	31	
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	57 (C/P) 59 (*1)	Instrument Panel No.2 Wire and Instrument Panel Wire (Behind the Radio and Player)

: Ground Points


Code	See Page	Ground Points Location
II	56 (C/P) 58 (*1)	Cowl Side Panel LH
IK	56 (C/P) 58 (*1)	Instrument Panel Brace LH
IL	56 (C/P) 58 (*1)	Instrument Panel Brace RH
IM	56 (C/P) 58 (*1)	Instrument Panel Reinforcement RH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Turn Signal and Hazard Warning Light



* 1 : C/P
 * 2 : Convertible



Turn Signal and Hazard Warning Light

: Parts Location

Code		See Page		Code		See Page		Code		See Page	
C7	A	44 (C/P) 46 (*1)		H10	A B	44 (C/P) 46 (*1)		R9	49 (C/P) 51 (*1)		
		44 (C/P) 46 (*1)				J3			49 (C/P) 51 (*1)		R10
F3	C9	40 (3MZ-FE) 42 (2AZ-FE)		J10	A	45 (C/P) 47 (*1)		T6	45 (C/P) 47 (*1)		
		40 (3MZ-FE) 42 (2AZ-FE)				J11			45 (C/P) 47 (*1)		

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2D		
2F	30	
2G	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2I		
2L	30	
2P	30	Floor Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P) 58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IF1	56 (C/P) 58 (*1)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IG5	56 (C/P) 58 (*1)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)

: Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE) 55 (2AZ-FE)	Right Fender
EC	54 (3MZ-FE) 55 (2AZ-FE)	Left Fender
II	56 (C/P) 58 (*1)	Cowl Side Panel LH
IM	56 (C/P) 58 (*1)	Instrument Panel Reinforcement RH
BT	60 (C/P) 61 (*1)	Back Panel Center

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Taillight



 : Parts Location

Code	See Page	Code	See Page	Code	See Page	
B6	A	44 (C/P) 46 (*1)	F4	40 (3MZ-FE) 42 (2AZ-FE)	R9	49 (C/P) 51 (*1)
						49 (C/P) 51 (*1)
C9		44 (C/P) 46 (*1)	J4	45 (C/P) 47 (*1)	R10	49 (C/P) 51 (*1)
						49 (C/P) 51 (*1)
F3		40 (3MZ-FE) 42 (2AZ-FE)	L1	48 (C/P) 50 (*1)		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2C		
2D		
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2P	30	Floor Wire and Driver Side J/B (Lower Finish Panel)

 : Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IK	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
BT	60 (C/P)	Back Panel Center
	61 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Stop Light



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
H13	A 48 (C/P)	R9	49 (C/P)	S12	45 (C/P)
	B 50 (*1)		51 (*1)		47 (*1)
J15	50 (*1)	R10	49 (C/P)		
N5	49 (C/P)		51 (*1)		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2M	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2P	30	Floor Wire and Driver Side J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
IP	56 (C/P)	Left Kick Panel
BR	60 (C/P)	Left Center Pillar
BT	60 (C/P)	Back Panel Center
	61 (*1)	
BV	61 (*1)	Front Side of Rear Quarter Panel LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Back-Up Light

* 1 : w/ Navigation System



 : Parts Location

Code	See Page	Code		See Page	Code	See Page
A3	40 (3MZ-FE)	J10	A	47 (*1)	R9	51 (*1)
	42 (2AZ-FE)	J11	B	45 (C/P)	R10	49 (C/P)
B1	42 (2AZ-FE)			47 (*1)		51 (*1)
J10	A	45 (C/P)	R9	49 (C/P)		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2H	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IM2	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
BT	60 (C/P)	Back Panel Center
	61 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Charging

* 1 : C/P, Convertible w/ VSC
 * 2 : Convertible w/o VSC
 * 3 : C/P
 * 4 : Convertible
 * 5 : 3MZ-FE
 * 6 : 2AZ-FE



 : Parts Location

Code	See Page	Code		See Page	Code	See Page
B9	44 (C/P)	G1	A	40 (3MZ-FE)	I15	45 (C/P)
	46 (*1)			42 (2AZ-FE)		47 (*1)
C7	44 (C/P)	G2	B	40 (3MZ-FE)	J11	45 (C/P)
	46 (*1)			42 (2AZ-FE)		47 (*1)

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
1E		
1L	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	
3B	36 (*2)	
3C	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG7	56 (C/P)	
	58 (*1)	
IG8	56 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	58 (*1)	
IG9	56 (C/P)	
IM1	57 (C/P)	
	59 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Key Reminder



System Outline

Key Reminder System

With the ignition key inserted in the key cylinder (Unlock warning SW on), the ignition SW still off and driver's door open (Door courtesy SW on), when a signal is input to TERMINAL (A) 10 of the combination meter, the combination meter operates, current flows from TERMINAL (A) 1 of the combination meter to TERMINAL (A) 20 GROUND and key reminder buzzer sounds.

: Parts Location

Code		See Page	Code		See Page	Code		See Page
C7	A	44 (C/P)	D5		50 (*1)	J12	A	45 (C/P)
		46 (*1)	J10	A	45 (C/P)		B	47 (*1)
C8	B	44 (C/P)			47 (*1)	U1		45 (C/P)
		46 (*1)	J11	B	45 (C/P)			47 (*1)
D5		48 (C/P)			47 (*1)			

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	
2G	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2)	
	37 (*3)	
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3C	37 (*3)	

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P) 58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IF1	56 (C/P) 58 (*1)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)


: Ground Points

Code	See Page	Ground Points Location
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Theft Deterrent and Door Lock Control





Theft Deterrent and Door Lock Control



System Outline

1. Manual Unlock Operation

When the door lock control SW of the driver's or passenger's side door is pushed to UNLOCK, the door lock will unlock.

2. Manual Lock Operation

When the door lock control SW of the driver's or passenger's side door is pushed to LOCK, the door lock will lock.

3. Door Key Unlock Operation

* Unlock operation from driver's side door

When the driver's side door is unlocked once using the ignition key, only the driver's side door is unlocked. If this operation is repeated within 3 seconds, all the other doors are unlocked.

* Unlock operation from front passenger's side door

When the front passenger's side door is unlocked using the ignition key, all the other doors are unlocked, too.

○ : Parts Location

Code		See Page		Code		See Page		Code		See Page		
B6	A	44 (C/P)		D8	A	48 (C/P)		J12	B	47 (*1)		
		46 (*1)			B	50 (*1)				48 (C/P)		
B7	B	44 (C/P)		D9		48 (C/P)		L3		50 (*1)		
		46 (*1)				50 (*1)				45 (C/P)		
B8	C	44 (C/P)		D10		48 (C/P)		S7		47 (*1)		
		46 (*1)				50 (*1)				41 (3MZ-FE)		
B9	D	44 (C/P)		E3		40 (3MZ-FE)		T1		43 (2AZ-FE)		
		46 (*1)				42 (2AZ-FE)				45 (C/P)		
D5		48 (C/P)		J3		45 (C/P)		U1		47 (*1)		
		50 (*1)		J10	A	45 (C/P)				45 (C/P)		
D6		48 (C/P)				47 (*1)		Z1		47 (*1)		
		50 (*1)		J11	B	45 (C/P)				45 (C/P)		
D7		48 (C/P)				47 (*1)		Z2		47 (*1)		
		50 (*1)		J12	A	45 (C/P)						

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1D		
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2H	31	
2J		Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K	30	
2M		
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3C	37 (*3)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Theft Deterrent and Door Lock Control

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA2	54 (3MZ-FE)	Engine Room Main Wire and Engine Room No.2 Wire (Radiator Side Support LH)
	55 (2AZ-FE)	
IA1	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IA2	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IG6	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IN1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IN2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IO2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR1	59 (*1)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)


 : Ground Points

Code	See Page	Ground Points Location
ED	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	58 (*1)	Instrument Panel Brace LH
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Wireless Door Lock Control





Wireless Door Lock Control





Wireless Door Lock Control

System Outline

Door lock control (Lock and unlock) and panic control (Theft alarm and flash) is performed by remote control, without the ignition key inserted in the door key cylinder, using low-power electrical waves emitted by a transmitter.

1. Wireless Door Lock or Unlock Normal Operation

With the ignition key not inserted into the ignition key cylinder (Unlock warning SW off) and all the doors completely closed, when the lock or unlock button (Transmitter) is pushed, the door control receiver receives the electrical waves from the transmitter, and sends a signal to the body ECU, causing it to operate.

As a result, the body ECU judges whether the door is locked or unlocked based on the signal from the door lock motor and door unlock detection SW, and sends a signal to switch the condition from lock to unlock or vice versa, causing the door lock motor to operate.

2. Visual Confirmation of Lock or Unlock

If all doors indicate that they are locked after the lock command, turn signal light will flash once. If any door indicates that it is open after the unlock command, turn signal light will flash twice.

3. Buzzer Sound Function

If all doors indicate that they are locked after the lock command, the keyless buzzer goes on once. If any door indicates that it is open after the unlock command, the keyless buzzer goes on twice.

4. Illuminated Entry Function

When the body ECU detects the unlock state after the unlock operation has been made, it turns on the lights, such as the ignition key cylinder light and interior light for approx. 15 sec. If all the doors are locked during this operation, lighting is cancelled and the lights immediately fade out.

5. Wireless Door Unlock Operation

Pushing the unlock button (Transmitter) once, driver's door is unlocked. Furthermore, pushing the button again within 3 seconds, the other doors are unlocked.

6. Automatic Lock Operation

With the ignition key not inserted into the ignition key cylinder (Unlock warning SW off) and all the doors completely closed, after pushing the button (Transmitter) to unlock all the doors, if a door is not opened within 30 seconds, all the doors will be automatically relocked.

7. Wireless Control Stop Function

If a door is open (Door courtesy SW on), a signal is input from the door courtesy SW to the body ECU stopping wireless door lock or unlock.

If the ignition key is in the ignition key cylinder (Unlock warning SW on), the unlock warning SW inputs a signal to the body ECU stopping wireless door lock or unlock.

8. Repeat Function

If the door lock or unlock condition does not change after wireless door lock or unlock operation, 2 seconds later, the body ECU sends current again to the door lock motor.

9. Remote Panic Operation

Panic will function when doors are locked or unlocked, open or closed. When the panic button (Transmitter) is pushed once, theft alarm and horn sounds and turn signal light, headlights and taillight flash. Then, the panic or the unlock button (Transmitter) is pushed once more, sounding and flashing will stop. Panic will not function when ignition key is in ignition key cylinder.

 : Parts Location

Code		See Page	Code		See Page	Code		See Page
B6	A	44 (C/P)	D6		50 (*1)	J10	A	47 (*1)
		46 (*1)	D7		48 (C/P)	J11	B	45 (C/P)
B7	B	44 (C/P)			50 (*1)		B	47 (*1)
		46 (*1)	D8	A	48 (C/P)	J12	A	45 (C/P)
B8	C	44 (C/P)		B	50 (*1)		B	47 (*1)
		46 (*1)	D9		48 (C/P)	K1		41 (3MZ-FE)
B9	D	44 (C/P)			50 (*1)			43 (2AZ-FE)
		46 (*1)	D10		48 (C/P)	L3	A	48 (C/P)
D4		44 (C/P)			50 (*1)		B	50 (*1)
		46 (*1)	H10	A	44 (C/P)		A	45 (C/P)
D5		48 (C/P)		B	46 (*1)	U1	B	47 (*1)
		50 (*1)	J3		45 (C/P)		C	
D6		48 (C/P)	J10	A	45 (C/P)		D	

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2G	31	
2H		Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2J		
2K	30	
2M		
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B	36 (*2)	
3C	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IA2	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IC1	56 (C/P) 58 (*1)	
IG5	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IN1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IN2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
	59 (*1)	
IO2	57 (C/P)	
IR1	59 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Wireless Door Lock Control

▽ : Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Moon Roof



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
B8	C	44 (C/P)	G4	48 (C/P)	J12 A 45 (C/P)
D5	48 (C/P)	J3	45 (C/P)	M4	48 (C/P)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	
2H	31	
2M	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2R		


 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IE1	56 (C/P)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)

 : Ground Points

Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH

Power Window for Coupe





Power Window for Coupe

System Outline

1. Manual Operation (Driver's Window)

With the ignition SW turned on and with the power window master SW in UP position, the current flowing from TERMINAL B1 or BW of the power window master SW flows to TERMINAL DU of the master SW to TERMINAL 1 of the power window motor to TERMINAL 2 to TERMINAL DD of the master SW to TERMINAL E to GROUND and causes the power window motor to rotate in the up direction. The window ascends only while the SW is being pushed.

In down operation, the flow of current from TERMINAL B1 or BW of the power window master SW to TERMINAL DD of the master SW causes the flow of current from TERMINAL 2 of the power window motor to TERMINAL 1 to TERMINAL DU of the master SW to TERMINAL E to GROUND, flowing in the opposite direction to manual up operation and causing the motor to rotate in reverse, lowering the window.

2. Auto Down Operation (Driver's Window)

When the driver's window SW is pushed strongly to the down side, the current flowing to TERMINAL B1 or BW of the power window master SW flows to the down contact point and auto down contact point of the driver's SW.

This activates the relay (Down side) inside the power window master SW and the hold circuit also turns on at the same time, so the relay (Down side) remains activated even when the SW is released.

Current flows at this time from TERMINAL B1 or BW of the power window master SW to TERMINAL DD to TERMINAL 2 of the power window motor to TERMINAL 1 to TERMINAL DU of the power window master SW to TERMINAL E to GROUND, so the motor continues to operate until the driver's window is fully down.

When the driver's window finishes down operation and the hold circuit goes off, so the relay (Down side) also turns off. This stops the current flowing from TERMINAL B1 or BW of the power window master SW to TERMINAL DD is cut off, so the power window motor stops and auto down operation stops.

When the driver's SW is pulled to the up side during auto down operation, the hold circuit is turned off so the current flowing from TERMINAL B1 or BW of the power window master SW to TERMINAL DD is cut off and the power window motor stops. If the SW remains pulled up the relay (Up side) is activated, so current flows from TERMINAL B1 or BW of the power window master SW to TERMINAL DU to TERMINAL 1 of the power window motor to TERMINAL 2 to TERMINAL DD to TERMINAL E to GROUND, the power window motor rotates in the up direction and manual up operation occurs while the SW is pulled up.

3. Manual Operation (Front RH Window)

With the power window control SW front RH pulled to the up side, the current flowing from TERMINAL 4 of the power window control SW flows to TERMINAL 3 of the power window control SW to TERMINAL 1 of the power window motor to TERMINAL 2 to TERMINAL 1 of the power window control SW to TERMINAL 2 to TERMINAL PD of the master SW to TERMINAL E to GROUND and causes the power window motor front RH to rotate in the up direction. The up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from TERMINAL 2 to TERMINAL 1, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the front RH window becomes open.

As a result, even if Open/Close operation of the front RH window is tried, the current from TERMINAL E of the power window master SW is not grounded and the motor does not rotate, so the front RH window can not be operated and window lock occurs.

4. Key Off Power Window Operation

With the ignition SW turned from on to off, the body ECU operates and current flows from the ECU-B fuse to TERMINAL 26 of the body ECU to TERMINAL 10 to TERMINAL 1 of the power relay to TERMINAL 2 to GROUND for about 43 seconds. The same as normal operation, the current flows from TERMINAL 5 of the PWR relay to TERMINAL 3 to the PWR fuse to TERMINAL B1 of the power window master SW and TERMINAL 4 of the power window control SW front RH. As a result, for about 43 seconds after the ignition SW is turned off, the functioning of this ECU makes it possible to raise and lower the power window. Also, by opening the front doors (Door courtesy SW on) within about 43 seconds after turning the ignition SW to off, a signal is input to TERMINAL (C) 14 of the body ECU. As a result, the PWR relay turns off, and up and down movement of the power window stops.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B8 C	44 (C/P)	J3	45 (C/P)	P7	49 (C/P)
D5	48 (C/P)	J10	45 (C/P)	P8	49 (C/P)
D8	48 (C/P)	J12 A	45 (C/P)	P9	49 (C/P)

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2H	31	
2J		Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K	30	
2M		


 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1		
IA2	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IN1		
IN2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

 : Ground Points


Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH

Convertible Roof and Power Window






Convertible Roof and Power Window



* 1 : w/ VSC
 * 2 : w/o VSC



Convertible Roof and Power Window

System Outline

1. Power Window Manual Down or Up Operation

When the power window control SW (Driver side) is pushed one step, the motor rotates and the driver's side window is opened while the switch is being pushed.

When the power window control SW (Driver side) is pulled up one step, the motor rotates and the driver's side window is closed while the switch is being pulled up.

The passenger side window can be opened/closed similarly, by operating the respective power window control SW.

The right and left quarter windows can be opened/closed by operating the power window SW (All window) at the same time.

2. Power Window Auto Down Operation

When the power window control SW (Driver side) is pushed down two steps, the motor rotates and the driver side window is opened fully.

3. Key Off Power Window Operation

The power window can be operated for a few seconds even after the ignition switch has been turned off. However, if any door is opened, the power window operation will be canceled.

4. Convertible Roof Open or Close Operation

When the sliding roof control SW is pushed to the OPEN side, the motor rotates and the convertible roof and all the windows are opened.

When the sliding roof control SW is pushed to the CLOSE side, the motor rotates in the opposite direction from open, and the convertible roof is closed and side windows go partially down and quarter windows go completely down.

○ : Parts Location

Code		See Page	Code		See Page	Code		See Page
B8	C	46 (*1)	D8		50 (*1)	P9		51 (*1)
	C7	46 (*1)		J3	47 (*1)	P19		47 (*1)
C17	B	50 (*1)		J12	B	Q1		51 (*1)
C18	A	50 (*1)		J15		Q2		51 (*1)
C19	C	50 (*1)		J16	A	S1		41 (3MZ-FE)
	C21	50 (*1)		J17	B	S2		41 (3MZ-FE)
	C22	50 (*1)		P7		S17		47 (*1)
	D5	50 (*1)		P8				

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2G	31	
2H		Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2J		
2K	30	
2M		
2O	30	Floor Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B	36 (*2)	
3C	37 (*3)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	58 (*1)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IA2		
IC1	58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IC2		
ID1	58 (*1)	Engine Room Main Wire and Floor No.1 Wire (Left Side of Driver Side J/B)
IG7	58 (*1)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IN1	59 (*1)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IN2		
IR2	59 (*1)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

 : Ground Points


Code	See Page	Ground Points Location
II	58 (*1)	Cowl Side Panel LH
IJ	58 (*1)	Instrument Panel Brace LH
BV	61 (*1)	Front Side of Rear Quarter Panel LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


VSC and Tire Pressure Warning System




* 1 : C/P
* 2 : Convertible




VSC and Tire Pressure Warning System





VSC and Tire Pressure Warning System



System Outline

The vehicle could be in an extreme over steering or under steering tendency due to unexpected accidents, road conditions, vehicle speed, or by other external factors. In such a case, this system automatically controls the engine output and the braking to each wheel, to decrease the extreme over steering and under steering.

* To decrease extreme over steering tendency

When the system determines that the over steering tendency is large, the system applies brakes to the outer wheels according to the degree of over steering, and creates a moment towards the outer side of the vehicle, to decrease the tendency of over steering. Also, when the brakes are applied, the vehicle speed decreases while the stability increases.

* To decrease extreme under steering tendency

When the system determines that the under steering tendency is large, the system applies brakes to the front or rear wheels according to the degree of under steering, to decrease the tendency of under steering.

* TRAC off SW

TRAC off SW is only for two-wheel drive models. Four-wheel drive models is needless this SW.

The SW to send the traction control system into OFF mode. When the SW is pushed after starting the engine, the system will be in OFF mode, and the TRAC OFF indicator light will turn on. When the SW is pushed again, the system will be in standby mode. When the engine is stopped and re-started, regardless of the TRAC off SW, the system will be in standby mode.

Information to the driver

The VSC system informs the driver when the tire grip is about to exceed its grip capacity, by blinking the slip indicator light and emitting an intermittent sound of the buzzer. Accordingly, the driver is informed to drive more gently.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	40 (3MZ-FE)	J1	47 (*1)	J12	B 47 (*1)
A4	40 (3MZ-FE)	J5	A 38, 47 (*1)	P3	45 (C/P)
A5	40 (3MZ-FE)		38, 45 (C/P)		47 (*1)
A28	A 48 (C/P)	J6	B 38, 47 (*1)	P6	45 (C/P)
	B 50 (*1)		38, 45 (C/P)		47 (*1)
A29	48 (C/P)	J7	C 38, 47 (*1)	S1	41 (3MZ-FE)
	50 (*1)		38, 45 (C/P)	S9	45 (C/P)
C5	44 (C/P)	J8	D 38, 47 (*1)		47 (*1)
	46 (*1)		38, 45 (C/P)	S12	45 (C/P)
C7	A 44 (C/P)	J9	E 38, 47 (*1)		47 (*1)
	46 (*1)		38, 45 (C/P)	T4	45 (C/P)
C8	B 44 (C/P)	J10	A 45 (C/P)		47 (*1)
	46 (*1)		47 (*1)	V11	45 (C/P)
D3	44 (C/P)	J11	B 45 (C/P)		47 (*1)
	46 (*1)		47 (*1)	Y1	45 (C/P)
E4	44 (C/P)	J12	A 45 (C/P)		47 (*1)
	46 (*1)		47 (*1)		
J1	45 (C/P)		B 45 (C/P)		

□ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)
2	25	VSC R/B (Engine Compartment Left)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

VSC and Tire Pressure Warning System



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1B		
1C		
1G		
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H	31	
2M	30	
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		



: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	56 (C/P)	Engine Room Main Wire and Floor No.1 Wire (Left Side of Driver Side J/B)
	58 (*1)	
IG4	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG7	56 (C/P)	
	58 (*1)	
IG8	56 (C/P)	
	58 (*1)	
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
IM2	57 (C/P)	
	59 (*1)	
IO2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR1	59 (*1)	






: Ground Points

Code	See Page	Ground Points Location
EB	54 (3MZ-FE)	Right Fender
ED	54 (3MZ-FE)	Left Fender
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


ABS and Tire Pressure Warning System





ABS and Tire Pressure Warning System





ABS and Tire Pressure Warning System

System Outline

This system controls the respective brake fluid pressures acting on the disc brake cylinders of the right front wheel, left front wheel and rear wheels when the brakes are applied in a panic stop so that the wheels do not lock. This results in improved directional stability and steerability during panic braking.

1. Input Signals

(1) Speed sensor signal

The speed of the wheels is detected and input to TERMINALS 5, 7, 10 and 19 of the skid control ECU with actuator.

(2) Stop light SW signal

A signal is input to TERMINAL 20 of the skid control ECU with actuator when the brake pedal is depressed.

2. System Operation

During sudden braking the skid control ECU with actuator has signals input from each sensor, which controls the current to the solenoid inside the actuator and lets the hydraulic pressure acting on each wheel cylinder escape to the reservoir. The pump inside the actuator is also operating at this time and it returns the brake fluid from the reservoir to the master cylinder, thus preventing locking of the vehicle wheels.

If the skid control ECU with actuator judges that the hydraulic pressure acting on the wheel cylinder is insufficient, the current on the solenoid is controlled and the hydraulic pressure is increased. Holding of the hydraulic pressure is also controlled by the skid control ECU with actuator, by the same method as above. Pressure reduction, holding and increase are repeated to maintain vehicle stability and to improve steerability during sudden braking.

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	40 (3MZ-FE)	C8	B	46 (*1)	J10 A 44 (C/P) 47 (*1)
	42 (2AZ-FE)	D3	A	46 (*1)	
A4	40 (3MZ-FE)			44 (C/P)	J11 B 45 (C/P) 47 (*1)
	42 (2AZ-FE)			46 (*1)	
A5	40 (3MZ-FE)	E4	B	44 (C/P)	P3 45 (C/P) 47 (*1)
	42 (2AZ-FE)	46 (*1)			
A28	A 48 (C/P)	E5	B	44 (C/P)	P6 45 (C/P) 47 (*1)
	B 50 (*1)			46 (*1)	
A29	48 (C/P)	G6	J1	45 (C/P)	S2 41 (3MZ-FE) 43 (2AZ-FE)
	50 (*1)			47 (*1)	
C7	A 44 (C/P)	J6	B	38, 45 (C/P)	S12 45 (C/P) 47 (*1)
	46 (*1)	J7	C	38, 45 (C/P)	
C8	B 44 (C/P)	J8	D	38, 45 (C/P)	

O : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
1G		
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2H	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M	30	
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	
3B	36 (*2)	
3C	37 (*3)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	56 (C/P)	Engine Room Main Wire and Floor No.1 Wire (Left Side of Driver Side J/B)
	58 (*1)	
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
	58 (*1)	
IG4	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG7	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG8	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	58 (*1)	
IG9	56 (C/P)	
IJ1	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	59 (*1)	
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
IM2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
	59 (*1)	
IO2	57 (C/P)	
IR1	59 (*1)	

: Ground Points

Code	See Page	Ground Points Location
EB	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
IJ	56 (C/P)	Instrument Panel Brace LH
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Memo


NOTICE: When inspecting or repairing the SRS, perform service in accordance with the following precautionary instructions and the procedure, and precautions in the Repair Manual applicable for the model year.


- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- **Work must be started more than 90 seconds after the ignition SW is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.**
(The SRS is equipped with a back-up power source so that if work is started within 90 seconds from disconnecting the negative (-) terminal cable of the battery, the SRS may deploy.)
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be cleared. So before starting work, make a record of the contents in the audio memory system. When work is finished, reset the audio systems as they were before and adjust the clock. Some vehicles have power tilt steering, power telescopic steering, power seat and power outside rear view mirror which are all equipped with memory function. However, it is not possible to make a record of these memory contents. So when the work is finished, it will be necessary to explain it to your customer, and ask the customer to adjust the features and reset the memory. To avoid erasing the memory in each system, never use a back-up power supply from outside the vehicle.
- Before repair, remove the airbag sensor if shocks are likely to be applied to the sensor during repair.
- Do not expose the following parts directly to hot air or flame;
- Even in cases of a minor collision where the SRS does not deploy, the following parts should be inspected;
- Never use SRS parts from another vehicle. When replacing parts, replace with new parts.
- For the purpose of reuse, never disassemble and repair the following parts.
- If the following parts have been dropped, or have cracks, dents and other defects in their case, bracket, and connector, replace with new one.
- Use a volt/ohmmeter with high impedance (10 kΩ/V minimum) for troubleshooting electrical circuits of the system.
- Information labels are attached to the periphery of the SRS components. Follow the instructions of the notice.
- After work on the SRS is completed, check the SRS warning light.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.

- * Steering wheel pad
 - * Front passenger airbag assembly
 - * Side airbag assembly
 - * Curtain shield airbag assembly
 - * Seat belt pretensioner
 - * Center airbag sensor assembly
 - * Front airbag sensor assembly
 - * Door side airbag sensor assembly
 - * Side airbag sensor assembly




* 1 : w/ Curtain Shielded Airbag
 * 2 : C/P, Convertible w/o VSC
 * 3 : Convertible w/o VSC
 * 4 : C/P
 * 5 : Convertible
 * 6 : 3MZ-FE
 * 7 : 2AZ-FE





* 4 : C/P
 * 5 : Convertible
 * 6 : 3MZ-FE
 * 7 : 2AZ-FE



System Outline

The SRS is a driver and front passenger protection device which has a supplemental role to the seat belts. When the ignition SW is turned to ON, the current from the IG2 fuse flows to TERMINAL (B) 21 of the airbag sensor assembly.

If an accident occurs while driving, when the frontal impact exceeds a set level, the current from the IG2 fuse flows to TERMINALS (B) 5, (B) 8, (B) 4, (B) 1, (A) 5 and (C) 4 of the airbag sensor assembly to the airbag squibs and the pretensioners to TERMINALS (B) 6, (B) 7, (B) 3, (B) 2, (A) 6 and (C) 3 of the airbag sensor assembly to TERMINAL (B) 25, (B) 26 or BODY GROUND to GROUND, so that current flows to the airbag squibs and the pretensioners and causes them to operate.

When the side impact also exceeds a set level, the current from the IG2 fuse flows to TERMINALS (A) 1, (C) 8, (A) 4 and (C) 5 of the airbag sensor assembly to the side airbag squibs and the curtain shield airbag squibs TERMINALS (A) 2, (C) 7, (A) 3 and (C) 6 of the airbag sensor assembly to TERMINAL (B) 25, (B) 26 or BODY GROUND to GROUND, causing side airbag squibs and curtain shield airbag squibs to operate.

The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver.

The airbag stored inside the passenger's instrument panel is instantaneously expanded to soften the shock to the front passenger.

Side airbags are instantaneously expanded to soften the shock of side to the driver and front passenger.

The curtain shield airbag can ease an impact on the head of the front and rear passengers and reduce risks of injury.

The pretensioners make sure of the seat belt restrainability.

○ : Parts Location

Code		See Page		Code		See Page		Code		See Page	
A9	40(3MZ-FE)	C5	44 (C/P)	J10	A	45 (C/P)	47 (*1)	J11	B	45 (C/P)	47 (*1)
	42(2AZ-FE)		46 (*1)							45 (C/P)	47 (*1)
A10	40(3MZ-FE)	C7	44 (C/P)	J11	B	45 (C/P)	47 (*1)	O2	A	52	
	42(2AZ-FE)		46 (*1)							O3	B
A21	A	44 (C/P)	C13	48 (C/P)	O4	52		O5	B	52	
		46 (*1)	C14	48 (C/P)							
A22	B	44 (C/P)	C15	48 (C/P)	O4	52		O6	A	52	
		46 (*1)	C16	48 (C/P)							
A23	C	44 (C/P)	D3	44 (C/P)	O6	52		O7	B	52	
		46 (*1)		46 (*1)							
A24	A	44 (C/P)	D11	A	48 (C/P)	P10	49 (C/P)	O8	A	52	
		46 (*1)		B	50 (*1)		51 (*1)				
A25	B	44 (C/P)	D12	A	48 (C/P)	P11	49 (C/P)	O9	B	52	
		46 (*1)		B	50 (*1)		51 (*1)				
A26		44 (C/P)	E4	A	44 (C/P)	S14	49 (C/P)	O10	A	52	
		46 (*1)			46 (*1)		51 (*1)				
B10		48 (C/P)	E5	B	44 (C/P)	S15	49 (C/P)	O11	B	52	
		50 (*1)			46 (*1)		51 (*1)				
B11		48 (C/P)	J1		45 (C/P)	O12		O13	A	52	
		50 (*1)			47 (*1)						

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2E	30	
2F		
2G	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H		
2M	30	
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	
3B	36 (*2)	
3C	37 (*3)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	56 (C/P)	Front Door LH Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
	58 (*1)	
IG1	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG5	56 (C/P)	
	58 (*1)	
IG7	56 (C/P)	
	58 (*1)	
IG9	56 (C/P)	
IO1	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IO2		
IP1	57 (C/P)	Front Door RH Wire and Floor No.2 Wire (Right Kick Panel)
	59 (*1)	
IR1	59 (*1)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

: Ground Points


Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
IO	56 (C/P)	Right Kick Panel
BX	61 (*1)	Under the Right Center Piller

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Cruise Control for 3MZ-FE




- * 1 : C/P, Convertible w/ VSC
- * 2 : Convertible w/o VSC



Cruise Control for 3MZ-FE



* 1 : C/P, Convertible w/ VSC
 * 2 : Convertible w/o VSC
 * 3 : w/ VSC
 * 4 : w/o VSC



Cruise Control for 3MZ-FE

System Outline

The cruise control system is a constant vehicle speed controller in which control of the switch on the instrument panel makes it possible to automatically adjust the opening of the engine throttle valve without depressing of the accel. pedal.

1. Set Operation

When the ON-OFF SW is turned on, the system starts preparations necessary for the cruise control and turns on the indicator light in the combination meter.

2. Set Speed Control

When the – SET SW is operated with the cruise control SW turned on during travelling, the constant vehicle speed is controlled.

3. Coast Control

When the – SET SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to decelerate the vehicle. Every time the – SET SW is turned on instantaneously, the vehicle speed is decelerated approximately 1.6 km/h.

4. Accel Control

When the + RES SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to accelerate the vehicle. Every time the + RES SW is turned on instantaneously, the vehicle speed is accelerated approximately 1.6 km/h.

5. Resume Control

When the vehicle speed is within the low speed limit (Approximately 40 km/h, 25 mph) if the cruise control is cancelled, use of the + RES SW accelerates the vehicle to the speed level used before canceling the cruise control.

6. Manual Cancel Mechanism

If any of the following signals is input during cruise control travelling, the cruise control is cancelled.

- * The stop light SW is turned on.
- * The CANCEL SW is turned on.
- * The ON-OFF SW is turned off.
- * Gear is shifted from D position to N position.
- * Gear is shifted from 4 to 3 in S mode.

7. Auto Cancel Function

If any of the following conditions is encountered, the cruise control is automatically cancelled.

- * The stop light SW wiring is faulty or short-circuited.
- * The vehicle speed signal is faulty.
- * The electronically controlled throttle malfunctions.

O : Parts Location

Code		See Page		Code		See Page		Code		See Page			
A3		40 (3MZ-FE)		E5	B	44 (C/P)		J2		47 (*1)			
A17		44 (C/P)				46 (*1)		J10	A	45 (C/P)			
		46 (*1)		E6	C	44 (C/P)				47 (*1)			
C7		44 (C/P)				46 (*1)		J11	B	45 (C/P)			
		46 (*1)		E7	D	44 (C/P)				47 (*1)			
C10		44 (C/P)				46 (*1)		S1	S2	41 (3MZ-FE)			
		46 (*1)		E8	E	44 (C/P)				41 (3MZ-FE)			
D3		44 (C/P)				46 (*1)		S12	T2	45 (C/P)			
		46 (*1)		J1		45 (C/P)				47 (*1)			
E4	A	44 (C/P)				47 (*1)		T2		41 (3MZ-FE)			
		46 (*1)				45 (C/P)							

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B		
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1H		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2H	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M	30	
3A	36 (*2) 37 (*3)	
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3C	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG5	56 (C/P) 58 (*1)	
IG7	56 (C/P) 58 (*1)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IG8	56 (C/P) 58 (*1)	
IJ1	57 (C/P) 59 (*1)	
IK1	57 (C/P) 59 (*1)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IM1	57 (C/P) 59 (*1)	
IM2	57 (C/P) 59 (*1)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)


 : Ground Points

Code	See Page	Ground Points Location
ED	54 (3MZ-FE)	Left Fender
EE	54 (3MZ-FE)	Right Side of Cylinder Head
EF	54 (3MZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P) 58 (*1)	Instrument Panel Brace LH
IM	56 (C/P) 58 (*1)	Instrument Panel Reinforcement RH


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Engine Control for 3MZ-FE







Engine Control for 3MZ-FE






Engine Control for 3MZ-FE





Engine Control for 3MZ-FE



System Outline

This system utilizes an engine control module and maintains overall control of the engine, transmission and so on. An outline of the engine control is explained here.

1. Input Signals

(1) Engine coolant temp. signal circuit

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the water temp. is input into TERMINAL THW of the engine control module as a control signal.

(2) Intake air temp. signal circuit

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal into TERMINAL THA of the engine control module.

(3) Oxygen sensor signal circuit

The oxygen density in the exhaust gases is detected and input as a control signal into TERMINALS OX1B and OX2B of the engine control module. To maintain stable detection performance by the heated oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HT1B and HT2B).

(4) Throttle signal circuit

The throttle position sensor detects the throttle valve opening angle as a control signal, which is input into TERMINALS VTA1 and VTA2 of the engine control module.

(5) Vehicle speed signal circuit

The vehicle speed sensor, detects the vehicle speed and input to ABS speed sensor of the skid control ECU with actuator, from skid control ECU with actuator to TERMINAL SPD of the engine control module, Via combination meter.

(6) Park/Neutral position SW signal circuit (A/T)

The Park/Neutral position SW detects whether the shift position is in neutral, parking or not, and inputs a control signal into TERMINAL NSW of the engine control module.

(7) A/C SW signal circuit

The A/C control assembly (Automatic A/C) or heater control SW (Manual A/C) inputs the A/C operations into TERMINAL ACS of the engine control module as a control signal.

(8) Battery signal circuit

Voltage is always supplied to TERMINAL BATT of the engine control module.

If you turn on the ignition SW, the current goes from TERMINAL MREL of the engine control module to the EFI relay and put on the relay, and the voltage related to the engine control module operation is supplied to TERMINALS +B and +B2 of the engine control module through the EFI relay.

(9) Intake air volume signal circuit

Intake air volume is detected by the mass air flow meter and a signal is input into TERMINAL VG of the engine control module as a control signal.

(10) Starter signal circuit

To confirm whether the engine is cranking, the voltage applied to the starter motor during cranking is detected and the signal is input into TERMINAL STA of the engine control module as a control signal.

(11) Engine knock signal circuit

Engine knocking is detected by the knock sensor No.1 and No.2, then the signals are input into TERMINALS KNK1 and KNK2 of the engine control module as a control signal.

(12) Air fuel ratio signal circuit

The air fuel ratio is detected and input as a control signal into TERMINALS A1A+, A2A+ of the engine control module.

Engine Control for 3MZ-FE

2. Control System

* SFI system

The SFI system monitors the engine condition through the signals, which are input from each sensor to engine control module. The best fuel injection volume is decided based on this data and the program memorized by the engine control module, and the control signal is output to TERMINALS #10, #20, #30, #40, #50 and #60 of the engine control module to operate the injector (Inject the fuel). The SFI system produces control of fuel injection operation by the engine control module in response to the driving conditions.

* ESA system

The ESA system monitors the engine condition through the signals, which are input to the engine control module from each sensor. The best ignition timing is decided according to this data and the memorized data in the engine control module, and the control signal is output to TERMINALS IGT1, IGT2, IGT3, IGT4, IGT5 and IGT6. This signal controls the igniter to provide the best ignition timing for the driving conditions.

* Heated oxygen sensor heater control system

The heated oxygen sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emissions is low), and warms up the heated oxygen sensor to improve detection performance of the sensor.

The engine control module evaluates the signals from each sensor, current is output to TERMINALS HT1B and HT2B, controlling the heater.

* Air fuel ratio sensor heater control system

The air fuel ratio sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emission is low), and warms up the air fuel ratio sensor to improve detection performance of the sensor.

The engine control module evaluates the signals from each sensor, current is output to TERMINALS HA1A and HA2A, controlling the heater.

* ACIS

ACIS includes a valve in the bulkhead separating the surge tank into two parts. This valve is opened and closed in accordance with the driving conditions to control the intake manifold length in two stages for increased engine output in all ranges from low to high speeds.

The engine control module judges the engine speed by the signals from each sensor and outputs current to the TERMINAL ACIS to control the VSV (ACIS).

3. Diagnosis System

With the diagnosis system, when there is a malfunction in the engine control module signal system, the malfunctioning system is recorded in the memory.

4. Fail-Safe System

When a malfunction occurs in any systems, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

○ : Parts Location

Code		See Page	Code		See Page	Code		See Page	
A3		40 (3MZ-FE)	F8		48 (C/P)	J11	B	47 (*1)	
A7		40 (3MZ-FE)			50 (*1)	J12	A	45 (C/P)	
A8		40 (3MZ-FE)	H6		40 (3MZ-FE)	J15	B	47 (*1)	
A11	A	44 (C/P)			40 (3MZ-FE)			50 (*1)	
		46 (*1)	H11	A	44 (C/P)	K3		41 (3MZ-FE)	
A17		44 (C/P)			46 (*1)		K4	41 (3MZ-FE)	
		46 (*1)	I1		41 (3MZ-FE)	M1		41 (3MZ-FE)	
A22		44 (C/P)	I2		41 (3MZ-FE)	P1		41 (3MZ-FE)	
		46 (*1)	I3		41 (3MZ-FE)	S1		41 (3MZ-FE)	
C4	A	40 (3MZ-FE)	I4		41 (3MZ-FE)	S2		41 (3MZ-FE)	
C7	A	44 (C/P)	I5		41 (3MZ-FE)	S12		45 (C/P)	
		46 (*1)	I6		41 (3MZ-FE)			47 (*1)	
C8	B	44 (C/P)	I7	A	41 (3MZ-FE)	T2		41 (3MZ-FE)	
		46 (*1)	I8	A	41 (3MZ-FE)			45 (C/P)	
D3		44 (C/P)	I9	A	41 (3MZ-FE)	T5		47 (*1)	
		46 (*1)	I10	A	41 (3MZ-FE)			V2	
E2	A	40 (3MZ-FE)	I11		41 (3MZ-FE)	V3		41 (3MZ-FE)	
E4	A	44 (C/P)	I12		41 (3MZ-FE)	V4		41 (3MZ-FE)	
		46 (*1)	I15		45 (C/P)		V5	A	
E5	B	44 (C/P)			47 (*1)	V6		41 (3MZ-FE)	
		46 (*1)	J1		45 (C/P)		V7	41 (3MZ-FE)	
E6	C	44 (C/P)			47 (*1)	V9		41 (3MZ-FE)	
		46 (*1)	J2		45 (C/P)		V10	41 (3MZ-FE)	
E7	D	44 (C/P)			47 (*1)	V14		49 (C/P)	
		46 (*1)	J10	A	45 (C/P)			51 (*1)	
E8	E	44 (C/P)			47 (*1)	V15		49 (C/P)	
		46 (*1)	J11	B	45 (C/P)			51 (*1)	

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Engine Control for 3MZ-FE

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
1B			
1C			
1D			
1E			
1H			
1J			
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)	
1L			
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2B			
2C			
2D			
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2H	31		
2I			
2M	30		
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
3B			
3C	37 (*3)		

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	54 (3MZ-FE)	Engine Wire and Sensor Wire (Left Bank of Cylinder Head)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
ID1	56 (C/P)	Engine Room Main Wire and Floor No.1 Wire (Left Side of Driver Side J/B)
	58 (*1)	
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG5	56 (C/P)	
	58 (*1)	
IG6	56 (C/P)	
	58 (*1)	
IG7	56 (C/P)	
	58 (*1)	
IG8	56 (C/P)	
	58 (*1)	
IJ1	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	59 (*1)	
IK1	57 (C/P)	
	59 (*1)	
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
IM2	57 (C/P)	
	59 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC





: Ground Points

Code	See Page	Ground Points Location
EC	54 (3MZ-FE)	Left Fender
ED		
EE	54 (3MZ-FE)	Right Side of Cylinder Head
EF	54 (3MZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P) 58 (*1)	Instrument Panel Brace LH
IM	56 (C/P) 58 (*1)	Instrument Panel Reinforcement RH
IP	56 (C/P)	Left Kick Panel
BR	60 (C/P)	Left Center Pillar
BV	61 (*1)	Front Side of Rear Quarter Panel LH


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Cruise Control for 2AZ-FE





Cruise Control for 2AZ-FE



System Outline

The cruise control system is a constant vehicle speed controller in which control of the switch on the instrument panel makes it possible to automatically adjust the opening of the engine throttle valve without depressing the accel. pedal.

1. Set Operation

When the ON-OFF SW is turned on, the system starts preparations necessary for the cruise control and turns on the indicator light in the combination meter.

2. Set Speed Control

When the – SET SW is operated with the cruise control SW turned on during travelling, the constant vehicle speed is controlled.

3. Coast Control

When the – SET SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to decelerate the vehicle. Every time the – SET SW is turned on instantaneously, the vehicle speed is decelerated approximately 1.6 km/h.

4. Accel Control

When the + RES SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to accelerate the vehicle. Every time the + RES SW is turned on instantaneously, the vehicle speed is accelerated approximately 1.6 km/h.

5. Resume Control

When the vehicle speed is within the low speed limit (Approximately 40 km/h, 25 mph) if the cruise control is cancelled, use of the + RES SW accelerates the vehicle to the speed level used before canceling the cruise control.

6. Manual Cancel Mechanism

If any of the following signals is input during cruise control travelling, the cruise control is cancelled.

- * The stop light SW is turned on.
- * The CANCEL SW is turned on.
- * The ON-OFF SW is turned off.
- * The clutch pedla depressed (M/T).
- * Gear is shifted from D position to N position. (A/T)
- * Gear is shifted from 4 to 3 in S mode.

7. Auto Cancel Function

If any of the following conditions is encountered, the cruise control is automatically cancelled.

- * The stop light SW wiring is faulty or short-circuited.
- * The vehicle speed signal is faulty.
- * The electronically controlled throttle malfunctions.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	42 (2AZ-FE)	E4	A	44 (C/P)	J10 A 45 (C/P)
A17	44 (C/P)	E5	B	44 (C/P)	J11 B 45 (C/P)
C7 A	44 (C/P)	E7	D	44 (C/P)	S2 43 (2AZ-FE)
C10	44 (C/P)	E8	E	44 (C/P)	S12 45 (C/P)
C12	44 (C/P)	J1		45 (C/P)	T2 43 (2AZ-FE)
D3	44 (C/P)	J2		45 (C/P)	

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M		
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Cruise Control for 2AZ-FE


 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG5		
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IG9		
IJ2		
IK2	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IM1		
IM2	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)

 : Ground Points


Code	See Page	Ground Points Location
ED	55 (2AZ-FE)	Left Fender
EG	55 (2AZ-FE)	Intake Side of Cylinder Block
EH	55 (2AZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P)	Instrument Panel Brace LH
IM	56 (C/P)	Instrument Panel Reinforcement RH


ECT and A/T Indicator for 3MZ-FE






ECT and A/T Indicator for 3MZ-FE





ECT and A/T Indicator for 3MZ-FE

* 1 : C/P, Convertible w/ VSC
 * 2 : Convertible w/o VSC
 * 5 : w/ VSC
 * 6 : w/o VSC



System Outline

Previous automatic transaxle have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the line pressure, throttle pressure, lock-up pressure and accumulator pressure etc. through the solenoid valve. The electronically controlled transmission is a system which precisely control gear shift timing and lock-up timing in response to the vehicle's driving conditions and the engine condition detected by various sensors. It makes smooth driving possible by shift selection for each gear which is the most appropriate to the driving conditions at that time, and by preventing dowling, squat and gear shift shock when starting off.

1. Gear Shift Operation

When driving, the engine warm up condition is input as a signal to TERMINAL THW of the engine control module from the engine coolant temp. sensor and the vehicle speed signal is input to TERMINAL SPD of the engine control module. At the same time, the throttle valve opening signal from the throttle position sensor is input to TERMINALS VTA1 and VTA2 of the engine control module as throttle angle signal.

Based on these signals, the engine control module selects the best shift position for the driving conditions and sends current to the electronically controlled transmission solenoid.

2. Lock-Up Operation

When each signal makes engine control module recognize that LOCK-UP condition is satisfied, the current flows from engine control module TERMINAL DSL to electronically controlled transmission solenoid TERMINAL 10. At the same time, the current flows engine control module TERMINAL SL1+ to electronically controlled transmission solenoid TERMINAL 6 and from TERMINAL 13 to engine control module TERMINAL SL1-. This works LOCK-UP solenoid to perform LOCK-UP operation.

3. Stop Light SW Circuit

If the brake pedal is depressed (Stop Light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine control module. The engine control module operates and cuts the current to the solenoid to release lock-up.

4. Sequential Shift Operation

With the sequential shift function, the manual shift lever becomes available by setting the shift lever to the S position, and the S and range display indicators appear in the combination meter. Any desired range can be selected by shifting up or down the shift lever.

○ : Parts Location

Code		See Page		Code		See Page		Code		See Page	
A3	40 (3MZ-FE)	E6	C	44 (C/P)	J10	A	45 (C/P)	J11	B	47 (*1)	47 (*1)
	44 (C/P)			46 (*1)			45 (C/P)			47 (*1)	47 (*1)
A16	46 (*1)	E7	D	44 (C/P)	J11	B	46 (*1)			41 (3MZ-FE)	41 (3MZ-FE)
	40 (3MZ-FE)			46 (*1)			41 (3MZ-FE)			41 (3MZ-FE)	41 (3MZ-FE)
C3	44 (C/P)	E8	E	44 (C/P)	S1	S2	45 (C/P)	S12	T2	47 (*1)	47 (*1)
	46 (*1)			46 (*1)			47 (*1)			41 (3MZ-FE)	41 (3MZ-FE)
C7 A		I15		45 (C/P)	S12	T3	45 (C/P)	T2	41 (3MZ-FE)	47 (*1)	47 (*1)
E1	40 (3MZ-FE)			47 (*1)			47 (*1)			41 (3MZ-FE)	41 (3MZ-FE)
E2 A	40 (3MZ-FE)	J1		45 (C/P)	T2	T3	45 (C/P)	41 (3MZ-FE)	41 (3MZ-FE)	47 (*1)	47 (*1)
E4 A	44 (C/P)			47 (*1)			47 (*1)			41 (3MZ-FE)	41 (3MZ-FE)
E5 B	44 (C/P)	J2		45 (C/P)	41 (3MZ-FE)	41 (3MZ-FE)	47 (*1)			41 (3MZ-FE)	41 (3MZ-FE)
	46 (*1)			47 (*1)			47 (*1)			41 (3MZ-FE)	41 (3MZ-FE)

□ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

ECT and A/T Indicator for 3MZ-FE



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B		
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1H		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2C		
2F	30	
2H	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2I		
2M	30	
3A	36 (*2) 37 (*3)	
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3C	37 (*3)	



: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG7	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG8	56 (C/P)	
	58 (*1)	
IJ1	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	59 (*1)	
IK1	57 (C/P)	
	59 (*1)	
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
IM2	57 (C/P)	
	59 (*1)	





: Ground Points

Code	See Page	Ground Points Location
ED	54 (3MZ-FE)	Left Fender
EE	54 (3MZ-FE)	Right Side of Cylinder Head
EF	54 (3MZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


ECT and A/T Indicator for 2AZ-FE






ECT and A/T Indicator for 2AZ-FE





ECT and A/T Indicator for 2AZ-FE



System Outline

Previous automatic transaxle have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the line pressure, throttle pressure, lock-up pressure and accumulator pressure etc. through the solenoid valve. The electronically controlled transmission is a system which precisely control gear shift timing and lock-up timing in response to the vehicle's driving conditions and the engine condition detected by various sensors. It makes smooth driving possible by shift selection for each gear which is the most appropriate to the driving conditions at that time, and by preventing dowling, squat and gear shift shock when starting off.

1. Gear Shift Operation

When driving, the engine warm up condition is input as a signal to TERMINAL THW of the engine control module from the engine coolant temp. sensor and the vehicle speed signal is input to TERMINAL SPD of the engine control module. At the same time, the throttle valve opening signal from the throttle position sensor is input to TERMINALS VTA1 and VTA2 of the engine control module as throttle angle signal.

Based on these signals, the engine control module selects the best shift position for the driving conditions and sends current to the electronically controlled transmission solenoid.

2. Lock-Up Operation

When each signal makes engine control module recognize that LOCK-UP condition is satisfied, the current flows from engine control module TERMINAL DSL to electronically controlled transmission solenoid TERMINAL 10. At the same time, the current flows engine control module TERMINAL SL1+ to electronically controlled transmission solenoid TERMINAL 6 and from TERMINAL 13 to engine control module TERMINAL SL1-. This works LOCK-UP solenoid to perform LOCK-UP operation.

3. Stop Light SW Circuit

If the brake pedal is depressed (Stop Light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine control module. The engine control module operates and cuts the current to the solenoid to release lock-up.

4. Sequential Shift Operation

With the sequential shift function, the manual shift lever becomes available by setting the shift lever to the S position, and the S and range display indicators appear in the combination meter. Any desired range can be selected by shifting up or down the shift lever.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	42 (2AZ-FE)	E7	D	44 (C/P)	J8 D 38, 45 (C/P)
A16	44 (C/P)	E8	E	44 (C/P)	J10 A 45 (C/P)
C3	42 (2AZ-FE)	G6		44 (C/P)	J11 B 45 (C/P)
C7 A	44 (C/P)	I15		45 (C/P)	S2 43 (2AZ-FE)
E1	42 (2AZ-FE)	J1		45 (C/P)	S12 45 (C/P)
E2 B	42 (2AZ-FE)	J2		45 (C/P)	T2 43 (2AZ-FE)
E4 A	44 (C/P)	J6	B	38, 45 (C/P)	T3 43 (2AZ-FE)
E5 B	44 (C/P)	J7	C	38, 45 (C/P)	

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

ECT and A/T Indicator for 2AZ-FE



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
1C			
1H			
1J			
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)	
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2C			
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2H	31		
2I			
2M	30		
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
3B			



: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IG9		
IJ2	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IK2		
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
IM2		




: Ground Points

Code	See Page	Ground Points Location
ED	55 (2AZ-FE)	Left Fender
EG	55 (2AZ-FE)	Intake Side of Cylinder Block
EH	55 (2AZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P)	Instrument Panel Brace LH
IM	56 (C/P)	Instrument Panel Reinforcement RH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Shift Lock



System Outline

Shift Lock Mechanism

If the brake pedal is depressed with the ignition SW set at ON (The stop light SW is on), the shift lock control ECU is activated, allowing the driver to change the shift lever to a position other than the P position.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
J3	45 (C/P)	J11	B	47 (*1)	S12
	47 (*1)	J12	A	45 (C/P)	
J10	A	45 (C/P)	B	47 (*1)	U1
			S8	45 (C/P)	
J11	B	45 (C/P)		47 (*1)	

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K		
2M		
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	


: Ground Points

Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Power Seat





Power Seat

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
J13	A 52	P13	52	P16	52
J14	B 52	P14	52	P17	52
P12	52	P15	52	P18	52

□ : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
2O	30	Floor Wire and Driver Side J/B (Lower Finish Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
BP	60 (C/P) 61 (*1)	Under the Driver's Seat

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Seat Heater



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
J4	45 (C/P)	J15	50 (*1)	S6	47 (*1)
	47 (*1)	S5	45 (C/P)	S13	49 (C/P)
J13 A	52		47 (*1)		51 (*1)
J14 B	52	S6	45 (C/P)	S16	52

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2M	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IO1	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR1	59 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
IK	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
BP	60 (C/P)	Under the Driver's Seat
	61 (*1)	
BQ	60 (C/P)	Under the Front Passenger's Seat
	61 (*1)	
BV	61 (*1)	Front Side of Rear Quarter Panel LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Seat Belt Warning





Seat Belt Warning

: Parts Location

Code		See Page	Code		See Page	Code		See Page	
A22	B	44 (C/P)	C5		44 (C/P)	J11	B	45 (C/P)	
		46 (*1)			46 (*1)			47 (*1)	
A23	C	44 (C/P)	C7		44 (C/P)	J12	A	45 (C/P)	
		46 (*1)			46 (*1)		B	47 (*1)	
B10		48 (C/P)	J1		45 (C/P)	J15		50 (*1)	
		50 (*1)			47 (*1)	O2		52	
B11		48 (C/P)	J10	A	45 (C/P)				
		50 (*1)			47 (*1)				

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H	31	
2M	30	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3A	36 (*2)	
3B	36 (*2)	
3C	37 (*3)	

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)	
	58 (*1)		
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)	
	58 (*1)		
IG7	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)	
	58 (*1)		
IG9	56 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)	
IO1	57 (C/P)		
IO2			
IR1	59 (*1)		

: Ground Points

Code	See Page	Ground Points Location
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
IO	56 (C/P)	Right Kick Panel
BP	60 (C/P)	Under the Driver's Seat
	61 (*1)	
BS	60 (C/P)	Right Center Pillar
BV	61 (*1)	Front Side of Rear Quarter Panel LH
BX	61 (*1)	Under the Right Center Piller

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Remote Control Mirror



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
J3	45 (C/P)	M2	48 (C/P)	R8	45 (C/P)
	47 (*1)		50 (*1)		47 (*1)
J12	A	45 (C/P)	M3	48 (C/P)	
	B	47 (*1)		50 (*1)	

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2K	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IN1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	

 : Ground Points

Code	See Page	Ground Points Location
II	56 (C/P) 58 (*1)	Cowl Side Panel LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Automatic Glare–Resistant EC Mirror with Compass



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
I16	48 (C/P) 50 (*1)	M2	48 (C/P) 50 (*1)		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2R		

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	56 (C/P) 58 (*1)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IE1	56 (C/P) 58 (*1)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)

 : Ground Points

Code	See Page	Ground Points Location
II	56 (C/P) 58 (*1)	Cowl Side Panel LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Garage Door Opener



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
G4	A 48 (C/P)	G5	B 50 (*1)		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G	31	
2R	30	
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	56 (C/P)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
	58 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Engine Control for 2AZ-FE






Engine Control for 2AZ-FE







Engine Control for 2AZ-FE


- * 1 : Shielded
- * 2 : Automatic A/C
- * 3 : Manual A/C





Engine Control for 2AZ-FE





Engine Control for 2AZ-FE

System Outline

The engine control system utilizes a microcomputer and maintains overall control of the engine, transaxle etc. An outline of the engine control is given here.

1. Input Signals

(1) Engine coolant temp. signal circuit

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance, which varies according to the engine coolant temp.. The engine coolant temp. which is input into TERMINAL THW of the engine control module as a control signal.

(2) Intake air temp. signal circuit

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp. which is input as a control signal to TERMINAL THA of the engine control module.

(3) Oxygen density signal circuit

The oxygen density in the exhaust emission is detected by the heated oxygen sensor and input as a control signal to TERMINAL OX1B of the engine control module (HT1B)

(4) RPM signal circuit

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to TERMINAL G2+ of the engine control module, and engine RPM is input into TERMINAL NE+.

(5) Throttle position signal circuit

The throttle position sensor detects the throttle valve opening angle as a control signal, which is input into TERMINALS VTA1 and VTA2 of the engine control module.

(6) Battery signal circuit

Voltage is constantly applied to TERMINAL BATT of the engine control module. With the ignition SW turned on, the voltage for engine control module start-up power supply is applied to TERMINAL +B of the engine control module via the EFI relay.

(7) Stop light SW signal circuit

The stop light SW is used to detect whether the vehicle is braking or not and the signal is input into TERMINAL STP of the engine control module as a control signal.

(8) Starter signal circuit

To confirm whether the engine is cranking, the voltage is applied to the starter motor during cranking is detected and the signal is input into TERMINAL STA of the engine control module as a control signal.

(9) Engine knock signal circuit

Engine knocking is detected by knock sensor and the signal is input into TERMINAL KNK1 as a control signal.

(10) Air fuel ratio signal system

The air fuel ratio is detected and input as a control signal into TERMINAL A1A+ of the engine control module.

2. Control System

- * SFI system

The SFI system monitors the engine condition through the signals input from each sensor to the engine control module. And the control signal is output to TERMINALS #10, #20, #30, #40 of the engine control module to operate the injector (Inject the fuel). The SFI system controls the fuel injection operation by the engine control module in response to the driving conditions.

- * ESA system

The ESA system monitors the engine condition through the signals input to the engine control module from each sensor. The best ignition timing is decided according to this data and the memorized data in the engine control module and the control signal is output to TERMINALS IGT1, IGT2, IGT3, IGT4. This signal controls the igniter to provide the best ignition timing for the driving conditions.

- * Heated oxygen sensor heater control system

The heated oxygen sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emissions is low), and warms up the heated oxygen sensor to improve detection performance of the sensor. The engine control module evaluates the signals from each sensor, and outputs current to TERMINAL HT1B to control the heater.

3. Diagnosis System

With the diagnosis system, when there is a malfunction in the engine control module signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can be found by reading the code displayed by the malfunction indicator lamp.

4. Fail-Safe System

When a malfunction has occurred in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	42 (2AZ-FE)	F8	48 (C/P)	J8	D 38, 45 (C/P)
A6	42 (2AZ-FE)	G6	44 (C/P)	J10	A 45 (C/P)
A17	44 (C/P)	H5	42 (2AZ-FE)	J11	B 45 (C/P)
A22	44 (C/P)	I1	43 (2AZ-FE)	J12	A 45 (C/P)
A32 C	44 (C/P)	I2	43 (2AZ-FE)	K2	43 (2AZ-FE)
A33	44 (C/P)	I3	43 (2AZ-FE)	M1	43 (2AZ-FE)
C1	42 (2AZ-FE)	I4	43 (2AZ-FE)	P1	43 (2AZ-FE)
C4 B	42 (2AZ-FE)	I7 B	43 (2AZ-FE)	S2	43 (2AZ-FE)
C6	44 (C/P)	I8 B	43 (2AZ-FE)	S12	45 (C/P)
C7 A	44 (C/P)	I9 B	43 (2AZ-FE)	T2	43 (2AZ-FE)
C8 B	44 (C/P)	I10 B	43 (2AZ-FE)	T5	45 (C/P)
D3	44 (C/P)	I15	45 (C/P)	V5 B	43 (2AZ-FE)
E2 B	42 (2AZ-FE)	J1	45 (C/P)	V8	43 (2AZ-FE)
E4 A	44 (C/P)	J2	45 (C/P)	V14	49 (C/P)
E5 B	44 (C/P)	J5 A	38, 45 (C/P)	V15	49 (C/P)
E7 D	44 (C/P)	J6 B	38, 45 (C/P)		
E8 E	44 (C/P)	J7 C	38, 45 (C/P)		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

Engine Control for 2AZ-FE



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1B		
1C		
1D		
1E		
1H		
1J		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
1L		
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2B		
2C		
2D		
2E	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2F		
2G	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H		
2I	30	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
2M		
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		



: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
ID1	56 (C/P)	Engine Room Main Wire and Floor No.1 Wire (Left Side of Driver Side J/B)
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IG5		
IG8		
IG9		
IJ2		
IK2	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
IM2		




: Ground Points

Code	See Page	Ground Points Location
ED	55 (2AZ-FE)	Left Fender
EG	55 (2AZ-FE)	Intake Side of Cylinder Block
EH	55 (2AZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P)	Instrument Panel Brace LH
IM	56 (C/P)	Instrument Panel Reinforcement RH
BR	60 (C/P)	Left Center Pillar

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Power Outlet



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
J4	45 (C/P)	P4	45 (C/P)	P5	45 (C/P)
	47 (*1)		47 (*1)		47 (*1)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
2M	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

 : Ground Points

Code	See Page	Ground Points Location
IK	56 (C/P) 58 (*1)	Instrument Panel Brace LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Horn



 : Parts Location


Code	See Page	Code	See Page	Code	See Page
C10	44 (C/P)	H8	40 (3MZ-FE)	H9	40 (3MZ-FE)
	46 (*1)		42 (2AZ-FE)		42 (2AZ-FE)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1H		
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2I	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Wiper and Washer



System Outline

With the ignition SW turned on, the current flows to TERMINAL 17 of the wiper and washer SW and TERMINAL 2 of the front wiper motor through the WIP fuse. The current flows to TERMINAL 2 of the washer motor through the WASH fuse.

1. Low Speed Position

With the wiper and washer SW turned to LO position, the current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and causes the front wiper motor to run at low speed.

2. High Speed Position

With the wiper and washer SW turned to HI position, the current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 8 to TERMINAL 4 of the front wiper motor to TERMINAL 5 to GROUND and causes the front wiper motor to run at high speed.

3. INT Position

With the wiper and washer SW turned to INT position, the wiper relay operates and current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 2 to GROUND. This activates the intermittent circuit and the current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and the wiper operates. Intermittent operation is controlled by a condenser charge and discharge function in the relay.

4. Washer Interlocking Operation

With the wiper and washer SW pulled to WASHER position (Washer SW ON position), the current flows from the WASHER fuse to TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 11 of the wiper and washer SW to TERMINAL 2 to GROUND and causes the washer motor to run and the window washer to spray. Simultaneously, current flows from the WIPER fuse to TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND, causing the wiper to function.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C11	44 (C/P)	F5	42 (2AZ-FE)	W2	41 (3MZ-FE)
	46 (*1)	J4	45 (C/P)		43 (2AZ-FE)
F5	40 (3MZ-FE)		47 (*1)		

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2C	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2I	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG8	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	

▽ : Ground Points

Code	See Page	Ground Points Location
ED	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IK	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Rear Window Defogger and Mirror Heater



 : Parts Location

Code		See Page		Code		See Page		Code		See Page		
A11	A	44 (C/P) 46 (*1)		J11	B	45 (C/P) 47 (*1)		N2		41 (3MZ-FE) 43 (2AZ-FE)		
A32	C	44 (C/P)		J15		50 (*1)		N4		49 (C/P)		
H11	A	44 (C/P) 46 (*1)		M2		48 (C/P) 50 (*1)		N7		51 (*1)		
								R13	A	49 (C/P)		
J10	A	45 (C/P) 47 (*1)		M3		48 (C/P) 50 (*1)		R14	B	49 (C/P)		
								R15		51 (*1)		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2D		
2J	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K		
2O	30	Floor Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IG6	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IN1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
ED	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
BU	60 (C/P)	Luggage Room Left
BV	61 (*1)	Front Side of Rear Quarter Panel LH
BW	61 (*1)	Near the Left Luggage Compartment Door


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Clock





Clock



: Parts Location

Code		See Page		Code		See Page		Code		See Page			
A1		40 (3MZ-FE)		F8		48 (C/P)		R2	A	45 (C/P)			
		42 (2AZ-FE)				50 (*1)				47 (*1)			
A11	A	44 (C/P)		I7	A	41 (3MZ-FE)		R3	B	45 (C/P)			
		46 (*1)				43 (2AZ-FE)				47 (*1)			
C5		44 (C/P)		J2		45 (C/P)		R6	B	45 (C/P)			
		46 (*1)				47 (*1)				47 (*1)			
C7	A	44 (C/P)		J10	A	45 (C/P)		R7	C	45 (C/P)			
		46 (*1)				47 (*1)				47 (*1)			
C8	B	44 (C/P)		J11	B	45 (C/P)		S1		41 (3MZ-FE)			
		46 (*1)				47 (*1)				41 (3MZ-FE)			
C10		44 (C/P)		J12	A	45 (C/P)		S2		43 (2AZ-FE)			
		46 (*1)				47 (*1)							

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1L	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2A	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2G	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K	30	
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B	36 (*2)	
3C	37 (*3)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P) 58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IF1	56 (C/P) 58 (*1)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IG6	56 (C/P) 58 (*1)	
IG7	56 (C/P) 58 (*1)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IG9	56 (C/P)	
IH1	57 (C/P) 59 (*1)	Instrument Panel No.2 Wire and Instrument Panel Wire (Behind the Radio and Player)
IK1	57 (C/P) 59 (*1)	
IK2	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IM1	57 (C/P) 59 (*1)	
IM2	57 (C/P) 59 (*1)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Clock






: Ground Points

Code	See Page	Ground Points Location
EH	55 (2AZ-FE)	Left Side of Cylinder Head
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IL	56 (C/P)	Instrument Panel Brace RH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Navigation and Audio System






Navigation and Audio System




* 1 : C/P
 * 2 : Convertible
 * 3 : Shielded
 * 4 : C/P, Convertible w/ VSC
 * 5 : Convertible w/o VSC



Navigation and Audio System

* 4 : C/P, Convertible w/ VSC
 * 5 : Convertible w/o VSC
 * 6 : w/ VSC
 * 7 : w/o VSC
 * 8 : 3MZ-FE
 * 9 : 2AZ-FE



System Outline

The navigation system displays the operating status and instructions for the radio and player. Additionally, the navigation system precisely measures the current vehicle position, displays the map obtained from the map database on the screen, and informs the route to the destination shown on the map using voice guidance.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	40 (3MZ-FE)	F7	50 (*1)	R12	B
	42 (2AZ-FE)		45 (C/P)		51 (*1)
A30	48 (C/P)	J10	47 (*1)	S1	41 (3MZ-FE)
	50 (*1)		45 (C/P)		41 (3MZ-FE)
C7	44 (C/P)	J11	47 (*1)	S2	43 (2AZ-FE)
	46 (*1)		45 (C/P)		45 (C/P)
C8	44 (C/P)	R5	47 (*1)	S10	47 (*1)
	46 (*1)		45 (C/P)		45 (C/P)
C10	44 (C/P)	R6	47 (*1)	S11	47 (*1)
	46 (*1)		45 (C/P)		45 (C/P)
C20	50 (*1)	R7	47 (*1)	T7	47 (*1)
F6	48 (C/P)		45 (C/P)		45 (C/P)
	50 (*1)	R11	A 49 (C/P)	T8	47 (*1)
F7	48 (C/P)		B 51 (*1)		51 (*1)
		R12	A 49 (C/P)	W5	51 (*1)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2G	31		
2H			
2K	30		
2M			
3A	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
	37 (*3)		
3B	36 (*2)		
3C	37 (*3)		

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IC2	58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IG7	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG9	56 (C/P)	
IH1	57 (C/P)	Instrument Panel No.2 Wire and Instrument Panel Wire (Behind the Radio and Player)
	59 (*1)	
IM2	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
IN2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IO2	57 (C/P)	
IR1	59 (*1)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR2		

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Navigation and Audio System



 : Ground Points

Code	See Page	Ground Points Location
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IL	56 (C/P)	Instrument Panel Brace RH
	58 (*1)	
BQ	61 (*1)	Under the Front Passenger's Seat
BX	61 (*1)	Under the Right Center Piller


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Audio System for Separate Type Amplifier without Navigation





Audio System for Separate Type Amplifier without Navigation



 : Parts Location

Code	See Page	Code		See Page	Code		See Page
A30	48 (C/P)	R6	B	45 (C/P)	S10	A	47 (*1)
	50 (*1)			47 (*1)			45 (C/P)
C10	44 (C/P)	R7	C	45 (C/P)	S11	B	47 (*1)
	46 (*1)			47 (*1)			45 (C/P)
C20	50 (*1)	R11	A	49 (C/P)	T7		47 (*1)
F6	48 (C/P)			B 51 (*1)			45 (C/P)
	50 (*1)	R12	A	49 (C/P)	T8		47 (*1)
F7	48 (C/P)			B 51 (*1)			W5 51 (*1)
	50 (*1)	S10	A	45 (C/P)			

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2H	31	
2K	30	
2M		

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IC2	58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IH1	57 (C/P)	Instrument Panel No.2 Wire and Instrument Panel Wire (Behind the Radio and Player)
	59 (*1)	
IN2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IO2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR1	59 (*1)	
IR2		

 : Ground Points

Code	See Page	Ground Points Location
IL	56 (C/P)	Instrument Panel Brace RH
	58 (*1)	
BQ	61 (*1)	Under the Front Passenger's Seat
BX	61 (*1)	Under the Right Center Piller

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Audio System for Built-In Type Amplifier



 : Parts Location

Code	See Page	Code		See Page	Code		See Page
A30	48 (C/P)	R2	A	45 (C/P)	R12	A	49 (C/P)
	50 (*1)			47 (*1)		B	51 (*1)
C10	44 (C/P)	R3	B	45 (C/P)	T7	45 (C/P)	
	46 (*1)			47 (*1)		47 (*1)	
F6	48 (C/P)	R4	C	45 (C/P)	T8	45 (C/P)	
	50 (*1)			47 (*1)		47 (*1)	
F7	48 (C/P)	R11	A	49 (C/P)			
	50 (*1)		B	51 (*1)			

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	
2H	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	56 (C/P)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	58 (*1)	
IC2	58 (*1)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
IN2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IO2	57 (C/P)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IR1	59 (*1)	

 : Ground Points


Code	See Page	Ground Points Location
IL	56 (C/P) 58 (*1)	Instrument Panel Brace RH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Combination Meter




- * 1 : Automatic A/C
- * 2 : 3MZ-FE
- * 3 : 2AZ-FE
- * 4 : Manual A/C
- * 5 : C/P, Convertible w/ VSC
- * 6 : Convertible w/o VSC



Combination Meter



* 2 : 3MZ-FE
 * 3 : 2AZ-FE
 * 7 : C/P
 * 8 : Convertible



Combination Meter

 : Parts Location

Code		See Page	Code		See Page	Code		See Page
B2		40(3MZ-FE)	F8		50 (*1)	J11	B	45 (C/P)
		42(2AZ-FE)			45 (C/P)			47 (*1)
C7	A	44 (C/P)	J1		47 (*1)	O1		41 (3MZ-FE)
		46 (*1)			45 (C/P)			43 (2AZ-FE)
C8	B	44 (C/P)	J3		47 (*1)	W1		41 (3MZ-FE)
		46 (*1)			45 (C/P)			43 (2AZ-FE)
F8		48 (C/P)	J10	A	47 (*1)			

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G	31	
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B	36 (*2)	
3C	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)
	58 (*1)	
IG5	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG6	56 (C/P)	
	58 (*1)	
IG7	56 (C/P)	
	58 (*1)	
IG9	56 (C/P)	
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	


 : Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
ED	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Radiator Fan and Condenser Fan





Radiator Fan and Condenser Fan

System Outline

Fan Motor Operation (3MZ-FE)

With the ignition SW turned on, the current through the HTR fuse flows to the FAN NO.1 relay (Coil side), FAN NO.2 relay (Coil side) and FAN NO.3 relay (Coil side).

1. Low Speed Operation

Only when the A/C system is activated or the water temp. SW No.2 is turned on, the condenser fan motor and the radiator fan motor rotates at low speed.

When the A/C system is activated, the current from HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the diode (A/C No.1) to TERMINAL 2 to TERMINAL (B) 2 of the engine control module causing the FAN NO.3 relay to turn on. As a result, the current through the CDS fuse flows to TERMINAL 5 of the FAN NO.3 relay to TERMINAL 3 to TERMINAL 2 of the condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 4 to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND. As this flowing in series for the motors, the motors rotate at low speed.

When the water temp. SW No.2 is turned on, the current from HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the water temp. SW No.2 to GROUND, causing the FAN NO.3 relay to turn on. As a result, the current through the CDS fuse flows the same route as above, rotating the motors at low speed.

2. High Speed Operation

With the pressure SW is turned on and/or the water temp. SW No.1 is turned on, the A/C condenser fan motor and the radiator fan motor rotate at high speed.

When the pressure SW is turned on, the current through the HTR fuse flows to the FAN NO.1 and NO.2 relay (Coil side) to TERMINAL 3 of the pressure SW to TERMINAL 2 to GROUND, and the current through the HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the water temp. SW No.2 to GROUND. As a result, FAN NO.1, NO.2, and NO.3 relay is turned on. At the same time, the current from the RDI fuse flows to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 5 to GROUND.

As the current flowing in parallel for motors as above, the motors rotate at high speed.

When the water temp. SW No.1 is turned on, the current through the HTR fuse flows to the FAN NO.1 and NO.2 relay (Coil side) to TERMINAL 2 of the water temp. SW No.1 to TERMINAL 1 to GROUND, and the current through the HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the water temp. SW No.2 to GROUND. As a result, FAN NO.1, NO.2 and NO.3 relay is turned on. At the same time, the current from the RDI fuse flows to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 5 to GROUND.

As the current flowing in parallel for motors as above, the motors rotate at high speed.

Fan Motor Operation (2AZ-FE)

With the ignition SW turned on, the current through the HTR fuse flows to the FAN NO.1 relay (Coil side), FAN NO.2 relay (Coil side) and FAN NO.3 relay (Coil side).

1. Low Speed Operation

When the ignition SW is turned on and the A/C system is activated, the condenser fan motor and the radiator fan motor rotates at low speed.

When the A/C system is activated, the current from HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the diode (A/C No.1) to TERMINAL 2 to TERMINAL (C) 16 of the A/C control assembly (Automatic A/C) or TERMINAL 12 of the A/C amplifier (Manual A/C) causing the FAN NO.3 relay to turn on. As a result, the current through the CDS fuse flows to TERMINAL 5 of the FAN NO.3 relay to TERMINAL 3 to TERMINAL 2 of the condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 4 to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND. As this flowing in series for the motors, the motors rotate at low speed.

2. High Speed Operation

When the pressure SW is turned on, the current through the HTR fuse flows to the FAN NO.1 and NO.2 relay (Coil side) to TERMINAL 3 of the pressure SW to TERMINAL 2 to GROUND, and the current through the HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the diode (A/C No.2) to TERMINAL 2 to TERMINAL 3 of the pressure SW to TERMINAL 2 to GROUND. As a result, FAN NO.1, NO.2, and NO.3 relay is turned on. At the same time, the current from the RDI fuse flows to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 5 to GROUND.

As the current flowing in parallel for motors as above, the motors rotate at high speed.

When the engine coolant is too high, the current through the HTR fuse flows to the FAN NO.1 and NO.2 relay (Coil side) to TERMINAL (A) 14 of the engine control module to GROUND, and the current through the HTR fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 1 of the diode (A/C No.2) to TERMINAL 2 to TERMINAL (A) 14 of the engine control module to GROUND. As a result, FAN NO.1, NO.2 and NO.3 relay is turned on. At the same time, the current from the RDI fuse flows to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 5 to GROUND.

As the current flowing in parallel for motors as above, the motors rotate at high speed.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A32	C	44 (C/P)	D2	42 (2AZ-FE)	P2
A33		44 (C/P)	E4	A	
C2		40 (3MZ-FE)	E5	B	44 (C/P)
		42 (2AZ-FE)			46 (*1)
D1		40 (3MZ-FE)	E6	C	44 (C/P)
		42 (2AZ-FE)			46 (*1)
					W3
					41 (3MZ-FE)
					W4
					41 (3MZ-FE)

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1F		
1G		
1H		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	54 (3MZ-FE)	Engine Room Main Wire and Engine Room No.2 Wire (Radiator Side Support LH)
	55 (2AZ-FE)	
EA2	54 (3MZ-FE)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
IG5	56 (C/P)	
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


Radiator Fan and Condenser Fan



: Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
ED	54 (3MZ-FE)	
	55 (2AZ-FE)	

Engine Immobiliser System



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
D3	44 (C/P)	J1	45 (C/P)	S7	45 (C/P)
	46 (*1)		47 (*1)		47 (*1)
D5	48 (C/P)	J10	45 (C/P)	T5	45 (C/P)
	50 (*1)		47 (*1)		47 (*1)
E5	44 (C/P)	J11	45 (C/P)	U1	45 (C/P)
	46 (*1)		47 (*1)		47 (*1)
I14	45 (C/P)	J12	A 45 (C/P)		
	47 (*1)		B 47 (*1)		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2M	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3C	37 (*3)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	56 (C/P)	Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)
	58 (*1)	
IG7	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG9	56 (C/P)	


 : Ground Points

Code	See Page	Ground Points Location
IM	56 (C/P) 58 (*1)	Instrument Panel Reinforcement RH


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Automatic Air Conditioning






Automatic Air Conditioning




* 1 : 3MZ-FE
 * 2 : 2AZ-FE
 * 3 : C/P, Convertible w/ VSC
 * 4 : Convertible w/o VSC



A11(A), A31(B), A32(C)
A/C Control Assembly

Automatic Air Conditioning



System Outline

1. Heater Blower Operation

Manual operation

When the blower speed is set to a certain level using the blower control SW, the A/C control assembly sends the signals to the blower control to control the blower motor speed.

Auto operation

When the auto SW is turned on, the A/C control assembly sends the signals from various sensors and temperature SW to the blower control to automatically control the blower motor speed.

2. Air Inlet Control Servo Motor Control

When the FRESH/RECIRC select SW is set to RECIRC, the motor in the air inlet control servo motor starts rotating to move the damper toward the RECIRC side. Since the damper position is detected by the TERMINAL TPI of the A/C control assembly, the motor is continuously rotated until the damper reaches its stop position. When the FRESH/RECIRC select SW is set to FRESH, the motor in the air inlet control servo motor starts rotating to move the damper toward the FRESH side. Since the damper position is detected by the TERMINAL TPI of the A/C control assembly, the motor is continuously rotated until the damper reaches its stop position.

3. Air Vent Mode Control Servo Motor Control

When the mode select SW is pushed, the ECU in the A/C control assembly activates the air vent mode control servo motor. This causes the servo motor to rotate to the position (FACE, BI-LEVEL, FOOT, FOOT/DEF, DEF) selected using the mode select SW, and moves the film damper.

4. Air Mix Control Servo Motor Control

When the temperature control SW is pressed, the ECU in the A/C control assembly sends a signal to the air mix control servo motor. This signal drives the motor to reach the temperature set by the temperature control SW, and moves the film damper.

5. Air Conditioning Operation

The A/C control assembly receives various signals, I.E., the engine RPM from the engine control module, out side air temperature signal from the A/C ambient temp. sensor, coolant temperature from the engine control module and the lock signal from the A/C compressor, etc.

If the A/C control assembly detects the following conditions, it stops the air conditioning:

- * Evaporator outlet air is too low.
- * There is a marked difference between the compressor speed and the engine speed.
- * The refrigerant pressure is abnormally high or abnormally low.
- * The engine speed is too low.
- * Rapid acceleration occurs.

○ : Parts Location

Code	See Page	Code		See Page	Code		See Page
A1	40(3MZ-FE)	A20	A	44(C/P)	E2	B	40(3MZ-FE)
	42(2AZ-FE)			46(*1)			42(2AZ-FE)
A2	40(3MZ-FE)	A31	B	44(C/P)	E5	C	44(C/P)
	42(2AZ-FE)			44(C/P)			46(*1)
A11	A	44(C/P)	B3	44(C/P)	E6	C	44(C/P)
				46(*1)			46(*1)
A12	44(C/P)	B4	44(C/P)	46(*1)	E8	E	44(C/P)
							46(*1)
A13	44(C/P)	C4	A	40(3MZ-FE)	J2	A	45(C/P)
				42(2AZ-FE)			47(*1)
A14	44(C/P)	C5	44(C/P)	46(*1)	J10	B	45(C/P)
							47(*1)
A18	44(C/P)	D1	40(3MZ-FE)	42(2AZ-FE)	J11	C	45(C/P)
							47(*1)
A19	44(C/P)	D3	44(C/P)	46(*1)	P2	D	41(3MZ-FE)
							43(2AZ-FE)

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Automatic Air Conditioning



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1J		
1L	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2G	31	
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B	36 (*2)	
3C	37 (*3)	



: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG3	56 (C/P)	
	58 (*1)	
IG5	56 (C/P)	
	58 (*1)	
IG6	56 (C/P)	
	58 (*1)	
II1	57 (C/P)	Instrument Panel Wire and Instrument Panel No.3 Wire (Behind the Glove Box)
	59 (*1)	
IJ1	57 (C/P)	
	59 (*1)	
IK1	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	59 (*1)	
IK2	57 (C/P)	
IL1	57 (C/P)	Instrument Panel Wire and Cowl No.2 Wire (Behind the Glove Box)
	59 (*1)	
IM1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
IM2	57 (C/P)	





: Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
EE	54 (3MZ-FE)	Right Side of Cylinder Head
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
IN	56 (C/P)	
	58 (*1)	


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Manual Air Conditioning






Manual Air Conditioning



* 3 : 3MZ-FE
* 4 : 2AZ-FE



Manual Air Conditioning

System Outline

1. Heater Blower Motor Operation

- * Low speed operation

When the heater control SW is moved to LO position, current flows to TERMINAL LO of the heater control SW to GROUND, activating the HTR relay. This causes the current to flow from the HTR (50A) fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to TERMINAL 2 of the blower motor to TERMINAL 1 to TERMINAL 1 of the blower resistor to TERMINAL 4 to GROUND, causing the blower motor to rotate at low speed.

- * Medium speed operation (Operation at M1, M2)

When the blower SW is moved to M1 position, current flows to TERMINAL LO of the heater control SW to GROUND, turning the HTR relay to switch on. This causes the current to flow from the HTR (50A) fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to TERMINAL 2 of the blower motor to TERMINAL 1 to TERMINAL 1 of the blower resistor to TERMINAL 2 to TERMINAL (B) 5 (3MZ-FE) or (C) 5 (2AZ-FE) of the heater control SW to GROUND. At this time, the blower resistance of the blower resistor is less than at low speed, so the blower motor rotates at medium low speed.

When the blower SW is moved to M2 position, current flows through the motor flows from TERMINAL 1 of the blower resistor to TERMINAL 3 to TERMINAL (B) 6 (3MZ-FE) or (C) 6 (2AZ-FE) of the heater control SW to GROUND. At this time, resistance of the blower resistor is less than at M1 position, so the blower motor rotates at medium high speed.

- * High speed operation

When the blower SW is moved to HIGH position, current flows to TERMINAL LO of the heater control SW to GROUND, turning the HTR relay to switch on.

This causes the current to flow from the HTR (50A) fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to TERMINAL 2 of the blower motor to TERMINAL 1 to TERMINAL (B) 7 (3MZ-FE) or (C) 7 (2AZ-FE) of the heater control SW to GROUND, causing the blower motor to rotate at high speed.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A2	40(3MZ-FE)	B5	44 (C/P)	H12	B 44 (C/P)
	42(2AZ-FE)		46 (*1)		46 (*1)
A14	44 (C/P)	D1	40(3MZ-FE)	J2	C 44 (C/P)
	46 (*1)		42(2AZ-FE)		45 (C/P)
A18	44 (C/P)	D3	44 (C/P)	J3	47 (*1)
	46 (*1)		44 (C/P)		45 (C/P)
A19	44 (C/P)	E5	44 (C/P)	J3	47 (*1)
	46 (*1)		46 (*1)		45 (C/P)
A20	44 (C/P)	E6	44 (C/P)	J10	A 45 (C/P)
	46 (*1)		46 (*1)		47 (*1)
A33	44 (C/P)	E8	44 (C/P)	J11	B 45 (C/P)
			46 (*1)		47 (*1)
B3	44 (C/P)	H11	44 (C/P)	P2	41 (3MZ-FE)
	46 (*1)		46 (*1)		43 (2AZ-FE)

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1J		
1L	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2D	30	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F	30	
2G	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B	36 (*2)	

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG2	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG3	56 (C/P)	
	58 (*1)	
IG5	56 (C/P)	
	58 (*1)	
IG6	56 (C/P)	
	58 (*1)	
II3	57 (C/P)	Instrument Panel Wire and Instrument Panel No.3 Wire (Behind the Glove Box)
	59 (*1)	
IK1	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	59 (*1)	
IL1	57 (C/P)	Instrument Panel Wire and Cowl No.2 Wire (Behind the Glove Box)
	59 (*1)	
IM2	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	

 : Ground Points

Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
EE	54 (3MZ-FE)	Right Side of Cylinder Head
II	56 (C/P)	Cowl Side Panel LH
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
IN	56 (C/P)	
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Multiplex Communication System – CAN for 3MZ-FE



System Outline

Multiplex communication system (CAN) uses a serial communication protocol and communicates with a differential voltage. In this network system, TERMINALS CANH and CANL are used for communication between the ECUs and sensors, and excellent data communication speed and communication error detecting facility are provided. This system is working for the following system:

- * VSC

○ : Parts Location

Code		See Page		Code		See Page		Code		See Page	
D3		44 (C/P)		J7	C	38, 45 (C/P)		J11	B	45 (C/P)	
		46 (*1)		J8	D	38, 47 (*1)				47 (*1)	
J5	A	38, 47 (*1)				38, 45 (C/P)		S1		41 (3MZ-FE)	
		38, 45 (C/P)		J9	E	38, 47 (*1)		S9		45 (C/P)	
J6	B	38, 47 (*1)				38, 45 (C/P)				47 (*1)	
		38, 45 (C/P)		J10	A	45 (C/P)		Y1		45 (C/P)	
J7	C	38, 47 (*1)				47 (*1)				47 (*1)	

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M		
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)

□ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG4	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	

▽ : Ground Points

Code	See Page	Ground Points Location
IJ	56 (C/P)	Instrument Panel Brace LH
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Multiplex Communication System – CAN for 2AZ-FE



System Outline

Multiplex communication system (CAN) uses a serial communication protocol and communicates with a differential voltage. In this network system, TERMINALS CANH and CANL are used for communication between the ECUs and sensors, and excellent data communication speed and communication error detecting facility are provided. This system is working for the following systems:

- * Engine Control
- * Electronically Controlled Transmission and A/T Indicator

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
E5	B	44 (C/P)	J6	B	38, 45 (C/P)
G6		44 (C/P)	J7	C	38, 45 (C/P)

O : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)


▽ : Ground Points

Code	See Page	Ground Points Location
IJ	56 (C/P)	Instrument Panel Brace LH

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

Multiplex Communication System – BEAN for 3MZ-FE

* 1 : C/P
* 2 : Convertible



System Outline

The multiplex communication system communicates among the engine control module and combination meter and controls the following systems according to the signals from respective sensors or switches.

Multiplex Communication System Includes Following Systems

- * Engine Control
- * Electronically Controlled Transmission and A/T Indicator
- * Combination Meter

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C7	44 (C/P) 46 (*1)	E5	B	44 (C/P) 46 (*1)	

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
3A	36 (*2) 37 (*3)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)

□ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	57 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IK1	59 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

2006 CAMRY SOLARA ELECTRICAL WIRING DIAGRAM SYSTEM CIRCUITS

	Page
ABS	178
Air Conditioning (Automatic A/C)	278
Air Conditioning (Manual A/C)	286
Audio System (Built-In Type Amplifier w/o Navigation System)	264
Audio System (Separate Type Amplifier w/o Navigation System)	260
Audio System (Separate Type Amplifier w/ Navigation System)	252
Automatic Glare-Resistant EC Mirror with Compass	234
Automatic Light Control	118
Back-Up Light	140
Charging	76
Clock	246
Combination Meter	266
Convertible Roof	164
Cruise Control (2AZ-FE)	198
Cruise Control (3MZ-FE)	192
Door Lock Control	144
Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212
Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
Engine Control (2AZ-FE)	90
Engine Control (3MZ-FE)	78
Engine Immobiliser System	102
Fog Light	116
Garage Door Opener	236
Headlight	112
Horn	240
Ignition (2AZ-FE)	72
Ignition (3MZ-FE)	68
Illumination	126
Interior Light	122
Key Reminder	142
Light Auto Turn Off System	120
Mirror Heater	244
Moon Roof	158
Multiplex Communication System (BEAN 2AZ-FE)	110
Multiplex Communication System (BEAN 3MZ-FE)	108
Multiplex Communication System (CAN 2AZ-FE)	106
Multiplex Communication System (CAN 3MZ-FE)	104
Navigation System	252
Power Outlet	238
Power Seat	222
Power Source	64
Power Window (Convertible)	164
Power Window (Coupe)	160
Radiator Fan and Condenser Fan	272
Rear Window Defogger	244
Remote Control Mirror	232
Seat Belt Warning	228

	Page
Seat Heater	226
Shift Lock	220
SRS	185
Starting (2AZ-FE)	72
Starting (3MZ-FE)	68
Stop Light	138
Taillight	136
Theft Deterrent	144
Tire Pressure Warning System (ABS)	178
Tire Pressure Warning System (VSC)	170
Turn Signal and Hazard Warning Light	132
VSC	170
Wiper and Washer	242
Wireless Door Lock Control	150



There are two types of wire harness for the instrument panel on CAMRY SOLARA.


Type A : The wire harness that uses the color-coded wire.

Type B : The wire harness that uses the same colored wire. (Not color-coded)

In case of using the same colored wires, each terminal number is printed on the wire as shown in the illustration on the left in order to distinguish each wiring.

Be sure to connect the terminal to the same place as indicated by the terminal number printed on the wire after disconnecting the terminal from the connector.

Multiplex Communication System – BEAN for 2AZ-FE



System Outline

The multiplex communication system communicates among the engine control module and combination meter and controls the following systems according to the signals from respective sensors or switches.

Multiplex Communication System Includes Following Systems

- * Engine Control
- * Electronically Controlled Transmission and A/T Indicator
- * Combination Meter

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C7	44 (C/P)	J10	A	45 (C/P)	J12
G6	44 (C/P)	J11	B	45 (C/P)	

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K		
2M		
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)


: Ground Points

Code	See Page	Ground Points Location
IM	56 (C/P)	Instrument Panel Reinforcement RH


* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC


I GROUND POINT






I GROUND POINT






I GROUND POINT



*11 : C/P
*12 : Convertible



I GROUND POINT

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
J2	45 (C/P)	J4		47 (*1)	J13 A 52
	47 (*1)	J10	A	45 (C/P)	J14 B 52
J3	45 (C/P)			47 (*1)	J15 50 (*1)
	47 (*1)	J11	B	45 (C/P)	J16 A 50 (*1)
J4	45 (C/P)			47 (*1)	J17 B 50 (*1)

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1J		
1K	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2E		
2F		
2M		
2R		
3A	36 (*2)	
	37 (*3)	
3B	36 (*2)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3C	37 (*3)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	54 (3MZ-FE)	Engine Room Main Wire and Engine Room No.2 Wire (Radiator Side Support LH)
	55 (2AZ-FE)	
EA2	54 (3MZ-FE)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	55 (2AZ-FE)	
IA1	56 (C/P)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
	58 (*1)	
IE1	56 (C/P)	Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG3	56 (C/P)	Instrument Panel No.2 Wire and Instrument Panel Wire (Behind the Radio and Player)
	58 (*1)	
IG7	56 (C/P)	Instrument Panel Wire and Instrument Panel No.3 Wire (Behind the Glove Box)
	58 (*1)	
IG9	56 (C/P)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	57 (C/P)	
IH1	57 (C/P)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	59 (*1)	
II1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
II2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IJ1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IJ2	57 (C/P)	
IM1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IM2	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	
IN1	57 (C/P)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	59 (*1)	

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

I GROUND POINT




: Ground Points


Code	See Page	Ground Points Location
EA	54 (3MZ-FE)	Right Fender
	55 (2AZ-FE)	
EB	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
EC	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
ED	54 (3MZ-FE)	Left Fender
	55 (2AZ-FE)	
EE	54 (3MZ-FE)	Right Side of Cylinder Head
EF	54 (3MZ-FE)	Left Side of Cylinder Head
EG	55 (2AZ-FE)	Intake Side of Cylinder Block
EH	55 (2AZ-FE)	Left Side of Cylinder Head
II	56 (C/P)	Cowl Side Panel LH
	58 (*1)	
IJ	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IK	56 (C/P)	Instrument Panel Brace LH
	58 (*1)	
IL	56 (C/P)	Instrument Panel Brace RH
	58 (*1)	
IM	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
IN	56 (C/P)	Instrument Panel Reinforcement RH
	58 (*1)	
IO	56 (C/P)	Right Kick Panel
IP	56 (C/P)	Left Kick Panel
BP	60 (C/P)	Under the Driver's Seat
	61 (*1)	
BQ	60 (C/P)	Under the Front Passenger's Seat
	61 (*1)	
BR	60 (C/P)	Left Center Pillar
BS	60 (C/P)	Right Center Pillar
BT	60 (C/P)	Back Panel Center
	61 (*1)	
BU	60 (C/P)	Luggage Room Left
BV	61 (*1)	Front Side of Rear Quarter Panel LH
BW	61 (*1)	Near the Left Luggage Compartment Door
BX	61 (*1)	Under the Right Center Piller

* 1 : Convertible * 2 : C/P, Convertible w/ VSC * 3 : Convertible w/o VSC

J POWER SOURCE (Current Flow Chart)




The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.





[LOCATION]

- ① : Engine Room R/B (See Page 24)
- ② : Engine Room J/B (See Page 26)
- ③ : Driver Side J/B (See Page 30)



J POWER SOURCE (Current Flow Chart)

Engine Room R/B (See Page 24)

Fuse		System	Page
5A	DRL	Headlight	112
10A	A/C	Manual Air Conditioning	286
15A	HEAD LH LWR	Headlight	112
15A	HEAD RH LWR	Headlight	112
40A	DEF	Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Rear Window Defogger and Mirror Heater	244
120A	ALT	Automatic Light Control	118
		Charging	80
		Clock	246
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212
		Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Fog Light	116
		Illumination	126
		Light Auto Turn Off System	120
		Power Window (Coupe)	160
		Starting and Ignition (2AZ-FE)	76
		Starting and Ignition (3MZ-FE)	72
		Taillight	136
		VSC and Tire Pressure Warning System	170

Engine Room J/B (See Page 26)

Fuse		System	Page
5A	ALT-S	Charging	76
10A	ETCS	Cruise Control (2AZ-FE)	198
		Cruise Control (3MZ-FE)	192
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212
		Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
10A	HEAD LH UPR	Headlight	112
10A	HEAD RH UPR	Headlight	112
10A	HORN	Horn	240
		Theft Deterrent and Door Lock Control	144
10A	IG2	ABS and Tire Pressure Warning System	178
		Charging	80
		Combination Meter	266
		Cruise Control (2AZ-FE)	198
		Cruise Control (3MZ-FE)	192
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	IG2	Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Engine Immobiliser System	102
		Seat Belt Warning	228
		SRS	185
		VSC and Tire Pressure Warning System	170
15A	HAZ	Turn Signal and Hazard Warning Light	132
15A	IGN	Clock	246
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Starting and Ignition (2AZ-FE)	72
		Starting and Ignition (3MZ-FE)	68
20A	EFI	Cruise Control (2AZ-FE)	198
		Cruise Control (3MZ-FE)	192
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212
		Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
25A	ABS NO.2	ABS and Tire Pressure Warning System	178
		VSC and Tire Pressure Warning System	170
25A	A/F	Engine Control (3MZ-FE)	78
25A	DOOR1	Theft Deterrent and Door Lock Control	144
		Wireless Door Lock Control	150
30A	AM2	Charging	76
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Starting and Ignition (2AZ-FE)	72
		Starting and Ignition (3MZ-FE)	68
30A	CDS	Radiator Fan and Condenser Fan	272
30A	RDI	Radiator Fan and Condenser Fan	272
30A	TSK	Convertible Roof and Power Window (Convertible)	164
40A	MAIN	Automatic Light Control	118
		Headlight	112
		Light Auto Turn Off System	120
50A	ABS NO.1	ABS and Tire Pressure Warning System	178
		VSC and Tire Pressure Warning System	170
50A	HTR	Automatic Air Conditioning	278
		Manual Air Conditioning	286

Driver Side J/B (See Page 30)

Fuse		System	Page
7.5A	AM1	Convertible Roof and Power Window (Convertible)	164
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	AM1	Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Starting and Ignition (2AZ-FE)	72
		Starting and Ignition (3MZ-FE)	68
7.5A	DOME	Clock	246
		Garage Door Opener	236
		Interior Light	122
		Wireless Door Lock Control	150
7.5A	ECU ACC	Automatic Light Control	118
		Clock	246
		Combination Meter	266
		Fog Light	116
		Headlight	112
		Interior Light	122
		Light Auto Turn Off System	120
		Moon Roof	158
		Multiplex Communication System (BEAN 2AZ-FE)	110
		Power Window (Coupe)	160
		Remote Control Mirror	232
		Shift Lock	220
		Theft Deterrent and Door Lock Control	144
		Wireless Door Lock Control	150
7.5A	OBD	Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
7.5A	P/W No.2	Convertible Roof and Power Window (Convertible)	164
10A	ECU-B	Automatic Air Conditioning	278
		Automatic Light Control	118
		Clock	246
		Combination Meter	266
		Convertible Roof and Power Window (Convertible)	164
		Engine Immobiliser System	102
		Fog Light	116
		Headlight	112
		Illumination	126
		Interior Light	122
		Key Reminder	142
		Light Auto Turn Off System	120
		Manual Air Conditioning	286
		Moon Roof	158
		Multiplex Communication System (BEAN 2AZ-FE)	110
		Multiplex Communication System (CAN 3MZ-FE)	104
		Navigation System and Audio System	252
		Power Window (Coupe)	160

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	ECU-B	Seat Belt Warning	228
		SRS	185
		Theft Deterrent and Door Lock Control	144
		VSC and Tire Pressure Warning System	170
		Wireless Door Lock Control	150
10A	ECU-IG	ABS and Tire Pressure Warning System	178
		Automatic Glare-Resistant EC Mirror with Compass	234
		Automatic Light Control	118
		Convertible Roof and Power Window (Convertible)	164
		Fog Light	116
		Headlight	112
		Interior Light	122
		Light Auto Turn Off System	120
		Moon Roof	158
		Multiplex Communication System (BEAN 2AZ-FE)	110
		Multiplex Communication System (CAN 3MZ-FE)	104
		Power Window (Coupe)	160
		Theft Deterrent and Door Lock Control	144
		VSC and Tire Pressure Warning System	170
		Wireless Door Lock Control	150
10A	FOG	Fog Light	116
10A	GAUGE1	ABS and Tire Pressure Warning System	178
		Back-Up Light	140
		Charging	76
		Clock	246
		Combination Meter	266
		Convertible Roof and Power Window (Convertible)	164
		Cruise Control (2AZ-FE)	198
		Cruise Control (3MZ-FE)	192
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212
		Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Key Reminder	142
		Navigation System and Audio System	252
		Seat Belt Warning	228
		Shift Lock	220
		Turn Signal and Hazard Warning Light	132
10A	HTR	VSC and Tire Pressure Warning System	170
		Automatic Air Conditioning	278
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Manual Air Conditioning	286
		Radiator Fan and Condenser Fan	272
		Rear Window Defogger and Mirror Heater	244


* These are the page numbers of the first page on which the related system is shown.


J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	MIR HTR	Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Rear Window Defogger and Mirror Heater	244
10A	PANEL	Clock	246
		Illumination	126
10A	RAD2	Audio System (Built-In Type Amplifier w/o Navigation System)	264
		Audio System (Separate Type Amplifier w/o Navigation System)	260
		Navigation System and Audio System	252
10A	TAIL	Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Fog Light	116
		Taillight	136
15A	CIG	Power Outlet	238
15A	P/POINT	Power Outlet	238
15A	STOP	ABS and Tire Pressure Warning System	178
		Cruise Control (2AZ-FE)	198
		Cruise Control (3MZ-FE)	192
		Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	212
		Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	204
		Engine Control (2AZ-FE)	90
		Engine Control (3MZ-FE)	78
		Shift Lock	220
		Stop Light	138
		VSC and Tire Pressure Warning System	170
15A	WASH	Wiper and Washer	242
20A	RAD1	Audio System (Built-In Type Amplifier w/o Navigation System)	264
		Audio System (Separate Type Amplifier w/o Navigation System)	260
		Navigation System and Audio System	252
20A	S-HTR	Seat Heater	226
25A	AMP	Audio System (Separate Type Amplifier w/o Navigation System)	260
		Navigation System and Audio System	252
25A	P/W	Power Window (Coupe)	160
25A	S/ROOF	Moon Roof	158
25A	WIP	Wiper and Washer	242
30A	P/SEAT	Power Seat	222
30A	PWR	Convertible Roof and Power Window (Convertible)	164
		Power Window (Coupe)	160


* These are the page numbers of the first page on which the related system is shown.
















K CONNECTOR LIST





K CONNECTOR LIST





K CONNECTOR LIST


*1 : 2AZ-FE Manual A/C

*2 : 3MZ-FE Manual A/C

H 1
Black




H 2
Black



H 3
Black



H 4
Black



H 5



H 6
Dark Gray



H 7
Black




H 8
Black




H 9
Black




H10
(C/P)




H10
(Convertible) Black




H11




H12
(*1) Black




H12
(*2)




H13
(C/P)




H13
(Convertible)




I 1
Black




I 2
Black




I 3
Black




I 4
Black




I 5
Black



I 6
Black




I 7
(2AZ-FE) Gray



I 7
(3MZ-FE) Gray




I 8
(2AZ-FE) Gray



I 8
(3MZ-FE) Gray




I 9
(2AZ-FE) Gray



I 9
(3MZ-FE) Gray






















I 10
(2AZ-FE) Gray























I 10
(3MZ-FE) Gray

























K CONNECTOR LIST











K CONNECTOR LIST







K CONNECTOR LIST





K CONNECTOR LIST





L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	B 6	Body ECU	90980-12561
A 2	A/C Lock Sensor	90980-11016	B 7	Body ECU	90980-12330
	A/C Magnetic Clutch		B 8	Body ECU	90980-12329
A 3	A/T Indicator Light SW	90980-12362	B 9	Body ECU	90980-12328
	Back-Up Light SW		B10	Buckle SW LH	90980-11034
	Park/Neutral Position SW			Seat Position Sensor	
A 4	ABS Speed Sensor Front LH	90980-11002	B11	Buckle SW RH	90980-10947
A 5	ABS Speed Sensor Front RH		C 1	Camshaft Position Sensor	
A 6	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980-11178	C 2	Condenser Fan Motor	90980-10928
A 7	Air Fuel Ratio Sensor (Bank 1 Sensor 1)		C 3	Counter Gear Speed Sensor	90980-11156
A 8	Air Fuel Ratio Sensor (Bank 2 Sensor 1)		C 4	Crankshaft Position Sensor	90980-10947
A 9	Airbag Sensor Front LH	90980-11898	C 5	Clock	90980-11915
A10	Airbag Sensor Front RH		C 6	Clutch Start SW	90980-10825
A11	A/C Control Assembly	90980-12169	C 7	Combination Meter	90980-12170
A12	A/C Room Temp. Sensor	90980-11918	C 8	Combination Meter	90980-12554
A13	A/C Solar Sensor		C 9	Combination SW	90980-11672
A14	A/C Thermistor		C10	Combination SW	90980-12552
A16	A/T Shift Lever Illumination	90980-12551	C11	Combination SW	90980-11594
	Transmission Control SW		C12	Cruise Control Clutch SW	90980-10906
A17	Accelerator Pedal Position Sensor	90980-11144	C13	Curtain Shield Airbag Sensor LH	90980-12241
A18	Air Inlet Control Servo Motor	90980-11909	C14	Curtain Shield Airbag Sensor RH	
A19	Air Mix Control Servo Motor		C15	Curtain Shield Airbag Squib LH	90980-11886
A20	Air Vent Mode Control Servo Motor (Automatic A/C)	90980-11909	C16	Curtain Shield Airbag Squib RH	
	Air Vent Mode Control Servo Motor (Manual A/C)	90980-11989	C17	Convertible Roof Control Relay	90980-10801
A21	Airbag Sensor Assembly	90980-12392	C18	Convertible Roof Control Relay	90980-12135
A22	Airbag Sensor Assembly	90980-12391	C19	Convertible Roof Control Relay	90980-10803
A23	Airbag Sensor Assembly	90980-12390	C20	Convertible Roof Courtesy SW	90980-11003
A24	Airbag Squib (Front Passenger Airbag Assembly)	90980-12219	C21	Convertible Roof Motor LH	90980-11162
A25	Airbag Squib (Front Passenger Airbag Assembly)	90980-12224	C22	Convertible Roof Motor RH	
A26	Airbag Squib (Steering Wheel Pad)	90980-12160	C23	Courtesy Light Rear RH	90980-11148
A27	Automatic Light Control Sensor	90980-11107	D 1	Diode (A/C No.1)	90980-11071
A28	ABS Speed Sensor Rear LH (C/P)	90980-11060	D 2	Diode (A/C No.2)	90980-10962
	ABS Speed Sensor Rear LH (Convertible)	90980-10859	D 3	Data Link Connector 3	90980-11665
A29	ABS Speed Sensor Rear RH	90980-11060	D 4	Door Control Receiver	90980-11909
A30	Antenna Amplifier	90980-10871	D 5	Door Courtesy SW LH	90980-10871
A31	A/C Control Assembly	90980-12554	D 6	Door Courtesy SW RH	
A32	A/C Control Assembly	90980-12259	D 7	Door Key Lock and Unlock SW LH	90980-12226
A33	A/C Amplifier	90980-10807		Door Lock Motor LH	
B 1	Back-Up Light SW	90980-11250		Door Unlock Detection SW LH	
B 2	Brake Fluid Level Warning SW	90980-11207	D 8	Door Lock Control SW LH	90980-12122
B 3	Blower Motor	90980-10903		Power Window Master SW	
B 4	Blower Motor Controller	90980-11676	D 9	Door Lock Control SW RH	90980-10797
B 5	Blower Resistor	90980-11136	D10	Door Lock Motor RH	90980-12226
				Door Unlock Detection SW RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
D11	Door Side Airbag Sensor LH (C/P)	90980-12241	H13	High Mounted Stop Light (C/P)	90980-10860
	Door Side Airbag Sensor LH (Convertible)	90980-11856		High Mounted Stop Light (Convertible)	90980-12062
D12	Door Side Airbag Sensor RH (C/P)	90980-12241	I 1	Ignition Coil and Igniter No.1	90980-11885
	Door Side Airbag Sensor RH (Convertible)	90980-11856	I 2	Ignition Coil and Igniter No.2	
E 1	Electronically Controlled Transmission Solenoid	90980-12326	I 3	Ignition Coil and Igniter No.3	
E 2	Engine Coolant Temp. Sensor (2AZ-FE)	90980-10735	I 4	Ignition Coil and Igniter No.4	
	Engine Coolant Temp. Sensor (3MZ-FE)	90980-10737	I 5	Ignition Coil and Igniter No.5	
E 3	Engine Hood Courtesy SW	90980-11003	I 6	Ignition Coil and Igniter No.6	
E 4	Engine Control Module	90980-12525	I 7	Injector No.1 (2AZ-FE)	90980-11875
E 5	Engine Control Module	90980-12529		Injector No.1 (3MZ-FE)	90980-11153
E 6	Engine Control Module	90980-12526	I 8	Injector No.2 (2AZ-FE)	90980-11875
E 7	Engine Control Module	90980-12528		Injector No.2 (3MZ-FE)	90980-11153
E 8	Engine Control Module	90980-12527	I 9	Injector No.3 (2AZ-FE)	90980-11875
F 1	Front Fog Light LH	90980-11095		Injector No.3 (3MZ-FE)	90980-11153
F 2	Front Fog Light RH		I10	Injector No.4 (2AZ-FE)	90980-11875
F 3	Front Parking Light LH	90980-11020		Injector No.4 (3MZ-FE)	90980-11153
	Front Turn Signal Light LH		I11	Injector No.5	90980-11153
F 4	Front Parking Light RH		I12	Injector No.6	
	Front Turn Signal Light RH		I14	Ignition Key Cylinder Light Transponder Key Amplifier	90980-12092
F 5	Front Wiper Motor	90980-11599	I15	Ignition SW	90980-11615
F 6	Front Door Speaker LH	90980-10935	I16	Inner Mirror	90980-11794
F 7	Front Door Speaker RH		I17	Interior Light	90980-10908
F 8	Fuel Pump	90980-11077	J 1	Junction Connector	90980-10803
	Fuel Sender		J 2	Junction Connector	90980-12346
G 1	Generator	90980-09213	J 3	Junction Connector	90980-11542
G 2	Generator	90980-11964	J 4	Junction Connector	90980-10976
G 3	Glove Box Light	90980-11098	J 5	Junction Connector	90980-12355
G 4	Garage Door Opener	90980-10789	J 6	Junction Connector	
	Moon Roof Control SW		J 7	Junction Connector	90980-10871
	Personal Light		J 8	Junction Connector	90980-12355
G 5	Garage Door Opener	90980-10621	J 9	Junction Connector	
	Vanity Light LH		J10	Junction Connector	90980-11661
G 6	Gateway ECU	90980-12404	J11	Junction Connector	
H 1	Headlight LH (High)	90980-11095	J12	Junction Connector	90980-11915
H 2	Headlight LH (Low)	82824-60460	J13	Junction Connector	90980-11661
H 3	Headlight RH (High)	90980-11095	J14	Junction Connector	
H 4	Headlight RH (Low)	82824-60460	J15	Junction Connector	90980-10976
H 5	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028	J16	Junction Connector	90980-11661
H 6	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-10869	J17	Junction Connector	
H 7	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028	K 1	Keyless Buzzer	90980-11142
H 8	Horn LH	90980-10619	K 2	Knock Sensor (Bank 1)	90980-11875
H 9	Horn RH		K 3	Knock Sensor (Bank 1)	
H10	Hazard SW	90980-10801	K 4	Knock Sensor (Bank 2)	
H11	Heater Control SW	90980-12200	L 1	License Plate Light	90980-11159
H12	Heater Control SW	90980-10926			


L PART NUMBER OF CONNECTORS


Code	Part Name	Part Number	Code	Part Name	Part Number
L 2	Luggage Compartment Light	90980-11148	Q 1	Quarter Power Window Motor LH	90980-10797
L 3	Luggage Compartment Door Opener Motor	90980-10825	Q 2	Quarter Power Window Motor RH	90980-10928
	Luggage Compartment Light SW		R 1	Radiator Fan Motor	
M 1	Mass Air Flow Meter	90980-11317	R 2	Radio and Player	90980-12259
M 2	Mirror Heater LH	90980-11923	R 3	Radio and Player	90980-10997
	Remote Control Mirror LH		R 4	Radio and Player	90980-10996
M 3	Mirror Heater RH		R 5	Radio and Player with Display	90980-11909
	Remote Control Mirror RH		R 6	Radio and Player (w/o Navigation System)	90980-12259
M 4	Moon Roof Control ECU and Motor	90980-10801		Radio and Player with Display (w/ Navigation System)	
N 1	Noise Filter (Ignition)	90980-10843	R 7	Radio and Player (w/o Navigation System)	90980-12038
N 2	Noise Filter (Rear Window Defogger)	90980-10928		Radio and Player with Display (w/ Navigation System)	
N 4	Noise Filter (Rear Window Defogger)	90980-10916	R 8	Remote Control Mirror SW	90980-11657
N 5	Noise Filter (Stop Light and Luggage Compartment Light)	90980-10860	R 9	Rear Combination Light LH	90980-10797
N 7	Noise Filter (Rear Window Defogger)	90980-10916	R10	Rear Combination Light RH	
O 1	Oil Pressure SW	90980-11363	R11	Rear Speaker LH (C/P)	90980-11299
O 2	Occupant Classification ECU	90980-12356		Rear Speaker LH (Convertible)	90980-10935
O 3	Occupant Classification ECU	90980-12357	R12	Rear Speaker RH (C/P)	90980-11299
O 4	Occupant Classification Sensor Front LH	90980-12353		Rear Speaker RH (Convertible)	90980-10935
O 5	Occupant Classification Sensor Front RH	90980-12354	R13	Rear Window Defogger	90980-10914
O 6	Occupant Classification Sensor Rear LH		R14	Rear Window Defogger	90980-10913
O 7	Occupant Classification Sensor Rear RH	90980-12353	R15	Rear Window Defogger	90980-10927
P 1	Power Steering Oil Pressure SW	90980-11428	S 1	Skid Control ECU with Actuator	90980-12297
P 2	Pressure SW	90980-10943	S 2	Skid Control ECU with Actuator	90980-98317
P 3	Parking Brake SW	90980-10871	S 3	Starter	90980-11400
P 4	Power Outlet (Front)	90980-10760	S 4	Starter	90980-09463
P 5	Power Outlet (Rear)	90980-10860	S 5	Seat Heater SW (Driver's Seat)	90980-10964
P 6	Pressure SW	90980-10906	S 6	Seat Heater SW (Front Passenger's Seat)	90980-10933
P 7	Power Window Motor Front LH	90980-10797	S 7	Security Indicator	90980-12063
P 8	Power Window Motor Front RH		S 8	Shift Lock Control ECU	90980-12552
P 9	Power Window SW Front RH	90980-10789		Transmission Control SW	
P10	Pretensioner LH	90980-12253	S 9	Steering Sensor	90980-12155
P11	Pretensioner RH		S10	Stereo Component Amplifier	90980-10821
P12	Power Seat Control SW (Driver's Seat Lumbar Support Control)	90980-10789	S11	Stereo Component Amplifier	90980-12200
P13	Power Seat Control SW (Driver's Seat)	90980-10997	S12	Stop Light SW	90980-11118
P14	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	S13	Seat Heater (Front Passenger's Seat)	90980-10935
P15	Power Seat Motor (Driver's Seat Lifter Control)		S14	Side Airbag Squib LH	90980-11864
P16	Power Seat Motor (Driver's Seat Lumbar Support Control)		S15	Side Airbag Squib RH	
P17	Power Seat Motor (Driver's Seat Reclining Control)		S16	Seat Heater (Driver's Seat)	90980-10935
P18	Power Seat Motor (Driver's Seat Slide Control)		S17	Sliding Roof Control SW	90980-10797
P19	Power Window SW (All Window)	90980-10996	T 1	Theft Deterrent Horn	90980-10619
P20	Personal Light	90980-11187	T 2	Throttle Control Motor	90980-11858
				Throttle Position Sensor	
			T 3	Turbine Speed Sensor	90980-11156
			T 4	TRAC Off SW	90980-10933

Note: Not all of the above part numbers of the connector are established for the supply.


Code	Part Name	Part Number	Code	Part Name	Part Number
T 5	Transponder Key Computer	90980-11911	V11	VSC Buzzer	90980-10906
T 6	Turn Signal Flasher Relay	90980-10799	V12	Vanity Light LH	90980-10621
T 7	Tweeter LH	90980-11013	V13	Vanity Light RH	
T 8	Tweeter RH		V14	Vapor Pressure Sensor	90980-11860
U 1	Unlock Warning SW	90980-10795	V15	VSV (Canister Closed Valve)	90980-11859
U 2	Upper Console Panel Sub-Assembly	90980-11918	W 1	Washer Level Sensor	90980-11068
V 2	VSV (ACIS)	90980-11149	W 2	Washer Motor	90980-10981
V 3	VSV (ACM)	90980-11156	W 3	Water Temp. SW No.1	90980-11235
V 4	VSV (AICV)		W 4	Water Temp. SW No.2	90980-11243
V 5	VSV (EVAP)	90980-10947	W 5	Woofer	90980-10795
V 6	VVT Sensor LH		Y 1	Yaw Rate Sensor	90980-11904
V 7	VVT Sensor RH	90980-11162	Z 1	Option Connector (TVIP ECU)	90980-10871
V 8	VVT Solenoid		Z 2	Option Connector (TVIP Glass Breakage Sensor ECU)	
V 9	VVT Solenoid LH	90980-11162			
V10	VVT Solenoid RH				

CAMRY SOLARA (EWD628U)







CAMRY SOLARA (EWD628U)




- * 1 : C/P
- * 2 : Convertible
- * 3 : 3MZ-FE
- * 4 : 2AZ-FE
- * 5 : C/P, Convertible w/ VS
- * 6 : Convertible w/o VSC



CAMRY SOLARA (EWD628U)



2 CAMRY SOLARA




CAMRY SOLARA (EWD628U)

M OVERALL ELECTRICAL WIRING DIAGRAM


3 CAMRY SOLARA

338



CAMRY SOLARA (EWD628U)


4 CAMRY SOLARA




M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)

340





M OVERALL ELECTRICAL WIRING DIAGRAM


(Cont. next page)

342


5 CAMRY SOLARA (Cont' d)

Engine Control (3MZ-FE)


* 3 : C/P, Convertible w/ VSC
 * 4 : Convertible w/o VSC
 * 5 : Shielded



E 4(A), E 5(B), E 6(C), E 7(D), E 8(E)
 Engine Control Module




CAMRY SOLARA (EWD628U)



M OVERALL ELECTRICAL WIRING DIAGRAM

5 CAMRY SOLARA (Cont' d)

344




CAMRY SOLARA (EWD628U)

M OVERALL ELECTRICAL WIRING DIAGRAM


(Cont. next page)

6 CAMRY SOLARA

346





CAMRY SOLARA (EWD628U)




M OVERALL ELECTRICAL WIRING DIAGRAM


(Cont. next page)

Engine Control (2AZ-FE)






6 CAMRY SOLARA (Cont'd)




CAMRY SOLARA (EWD628U)




CAMRY SOLARA (EWD628U)


7 CAMRY SOLARA (Cont' d)



CAMRY SOLARA (EWD628U)



Electronically Controlled Transmission and A/T Indicator (2AZ-FE)




M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)

8 CAMRY SOLARA (Cont' d)

356



CAMRY SOLARA (EWD628U)

8 CAMRY SOLARA (Cont' d)


Multiplex Communication System (CAN 2AZ-FE)

13


14

15

16




9 CAMRY SOLARA




- * 1 : C/P
- * 2 : Convertible

Noise Filter
(Stop Light and Luggage Compartment Light)


CAMRY SOLARA (EW628U)




10 CAMRY SOLARA (Cont' d)



M OVERALL ELECTRICAL WIRING DIAGRAM




12 CAMRY SOLARA




M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)

364



13 CAMRY SOLARA (Cont' d)





M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)

14 CAMRY SOLARA


366






14 CAMRY SOLARA (Cont'd)

VSC and Tire Pressure Warning System




Multiplex Communication System (CAN 3MZ-FE)



CAMRY SOLARA (EWD628U)

15 CAMRY SOLARA




CAMRY SOLARA (EWD628U)


M OVERALL ELECTRICAL WIRING DIAGRAM

16 CAMRY SOLARA

370




CAMRY SOLARA (EWD628U)



18 CAMRY SOLARA

3
2


CAMRY SOLARA (EWD628U)



19 CAMRY SOLARA

CAMRY SOLARA (EW/D628U)


373



M OVERALL ELECTRICAL WIRING DIAGRAM

20 CAMRY SOLARA


374




CAMRY SOLARA (EWD628U)

21 CAMRY SOLARA


CAMRY SOLARA (EW/D628U)



CAMRY SOLARA (EW628U)



23 CAMRY SOLARA





M OVERALL ELECTRICAL WIRING DIAGRAM

24 CAMRY SOLARA

۳۷

CAMRY SOLARA (EW628U)







25 CAMRY SOLARA (Cont'd)

Navigation System, Audio System (Separate Type Amplifier w/ Navigation System)

- * 2 : C/P
- * 3 : Convertible






26 CAMRY SOLARA (Cont' d)

Audio System (Separate Type Amplifier w/o Navigation System)

* 2 : C/P
* 3 : Convertible




M OVERALL ELECTRICAL WIRING DIAGRAM


27 CAMRY SOLARA

384

CAMRY SOLARA (EWD628U)



CAMRY SOLARA (EWD628U)



Combination Meter


* 2 : 3MZ-FE
* 3 : 2AZ-FE

5

6

7


8




M OVERALL ELECTRICAL WIRING DIAGRAM

28 CAMRY SOLARA (Cont'd)

388




29 CAMRY SOLARA



CAMRY SOLARA (EWD628U)

CAMRY SOLARA (EWD628U)



Automatic Air Conditioning


* 1 : 3MZ-FE
* 2 : 2AZ-FE

5

6

7

8




30 CAMRY SOLARA (Cont'd)

392

Automatic Air Conditioning

9 10 11 12




M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)


31 CAMRY SOLARA

394




CAMRY SOLARA (EWD628U)

Manual Air Conditioning



M OVERALL ELECTRICAL WIRING DIAGRAM

31 CAMRY SOLARA (Cont'd)




M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)


32 CAMRY SOLARA

398



CAMRY SOLARA (EW628U)


Convertible Roof and Power Window



M OVERALL ELECTRICAL WIRING DIAGRAM

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

HOW TO READ THIS SECTION



[A] : System Title


[B] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black	W = White	BR = Brown
L = Blue	V = Violet	SB = Sky Blue
R = Red	G = Green	LG = Light Green
P = Pink	Y = Yellow	GR = Gray
O = Orange		

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y




[C] : The position of the parts is the same as shown in the wiring diagram and wire routing.

[D] : Indicates the pin number of the connector.


The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right



Female

Numbered in order from upper right to lower left



Male

The numbering system for the overall wiring diagram is the same as above


[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : (1) Indicates Relay Block No.1

[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it).

Junction Blocks are shaded to clearly separate them from other parts.


Example:



3C indicates that it is inside Junction Block No.3

[G] : Indicates related system.

[H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (▼). Outside numerals are pin numbers.



Female

Male (▼)

[I] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

[J] : Indicates a shielded cable.



[K] : Indicates and located on ground point.

[L] : The same code occurring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX

SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS	15-2	Light Auto Turn Off System	1-6
Audio System (Built-in Type Amplifier w/o Navigation System)	27-3	Manual Air Conditioning	31-3
Audio System (Separate Type Amplifier w/o Navigation System)	26-2	Mirror Heater	19-4
Audio System (Separate Type Amplifier w/ Navigation System)	25-2	Moon Roof	20-4
Automatic Air Conditioning	30-3	Multiplex Communication System (BEAN) (2AZ-FE)	8-11
Automatic Glare-Resistant EC Mirror with Compass	20-2	Multiplex Communication System (BEAN) (3MZ-FE)	7-8
Automatic Light Control	1-8	Multiplex Communication System (CAN) (2AZ-FE)	8-13
Back-Up Light	12-2	Multiplex Communication System (CAN) (3MZ-FE)	14-11
Charging	4-2	Navigation System	25-2
Clock	24-2	Power Outlet	22-2
Combination Meter	28-2	Power Seat	23-2
Convertible Roof	32-3	Power Source	1-32-1
Cruise Control (2AZ-FE)	6-17	Power Window (Coupe)	17-2
Cruise Control (3MZ-FE)	5-17	Power Window (Convertible)	32-3
Door Lock Control	1-17	Radiator Fan and Condenser Fan	29-2
Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	8-2	Rear Window Defogger	19-2
Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	7-2	Remote Control Mirror	18-3
Engine Control (2AZ-FE)	6-8	Seat Belt Warning	16-2
Engine Control (3MZ-FE)	5-8	Seat Heater	22-4
Engine Immobiliser System (2AZ-FE)	6-3	Shift Lock	22-3
Engine Immobiliser System (3MZ-FE)	5-3	SRS	13-2
Fog Light	1-2	Starting (2AZ-FE)	3-2
Garage Door Opener	1-9	Starting (3MZ-FE)	2-2
Headlight	1-6	Stop Light	9-3
Horn	16-4	Taillight	9-2
Ignition (2AZ-FE)	3-2	Theft Deterrent	1-15
Ignition (3MZ-FE)	2-2	Tire Pressure Warning System (ABS)	15-2
Illumination	10-2	Tire Pressure Warning System (VSC)	14-2
Interior Light	1-9	Turn Signal and Hazard Warning Light	11-2
Key Reminder	1-12	VSC	14-2
		Wiper and Washer	21-3
		Wireless Door Lock Control	1-13

